SONY

User Guide

Personal Computer
VGN-BZ series

Downloaded from LpManual.com Manuals

Contents

Before Use 4
- Finding More about Your VAIO Computer 5
- Ergonomic Considerations 7

Getting Started 9
- Locating Controls and Ports 10
- About the Indicator Lights 17
- Connecting a Power Source 18
- Using the Battery Pack 19
- Shutting Down Your Computer Safely 26
- Updating Your Computer 27

Using Your VAIO Computer 28
- Using the Keyboard 29
- Using the Touch Pad 31
- Using Special-function Buttons 32
- Using the Built-in Camera 33
- Using the Optical Disc Drive 35
- Using the Memory Stick 43
- Using Other Modules / Memory Cards 49
- Using the Internet 56
- Using the Network (LAN) 58
- Using the Wireless LAN 60
- Using the Bluetooth Function 68
- Using Fingerprint Authentication 73
- Using the TPM 80

Using Peripheral Devices 85
- Connecting a Docking Station 86
- Connecting External Speakers or Headphones 94
- Connecting an External Display 95
- Selecting Display Modes 100
- Using the Multiple Monitors Function 102
- Connecting an External Microphone 104
- Connecting a USB Device 105
- Connecting an i.LINK Device 107

Customizing Your VAIO Computer 109
- Setting the Password 110
- Using the VAIO Control Center 122
- Using the Power Saving Modes 123
- Using the VAIO Power Management 128
- Protecting Data from Unauthorized Use 130
- Protecting the Hard Disk 133
- Configuring Your Modem 134

Upgrading Your VAIO Computer 136
- Adding and Removing Memory 137

Downloaded from LpManual.com Manuals

Precautions 143
Handling the LCD Screen 144
Using the Power Source 145
Handling Your Computer 146
Handling the Built-in Camera 149
Handling Discs 150
Using the Battery Pack 151
Using Headphones 152
Handling the Memory Stick 153
Handling the Built-in Storage Device 154
Using Fingerprint Authentication 155
Using the TPM 156
Troubleshooting 158
Computer 160
System Security 166
Battery 167
Built-in Camera 169
Internet 171
Networking 173
Bluetooth Technology 178
Optical Discs 182
Display 186
Printing 190
Microphone 192
Speakers 193
Touch Pad 194
Keyboard 195
Floppy Disks 196
PC Cards 197
Audio/Video 199
Memory Stick 201
Peripherals 202
Docking Station 204
Trademarks 205
Notice 207

Downloaded from LpManual.com Manuals

Before Use

Congratulations on your purchase of this Sony VAIO® computer, and welcome to the on-screen User Guide. Sony has combined leading-edge technology in audio, video, computing, and communications to provide state-of-the-art personal computing experience.

! External views illustrated in this manual may look slightly different from those of your computer.

Information in the supplied manuals including this User Guide is intended for users of the VAIO computers with the Microsoft® Windows Vista® 32-bit operating system. You may find differences in the information when your computer comes preinstalled with the 64-bit operating system.

How to find specifications

Some features, options, and supplied items may not be available on your computer.

To find out about the configuration of your computer, visit the VAIO Link web site at http://www.vaio-link.com.

Downloaded from LpManual.com Manuals

Finding More about Your VAIO Computer

This section provides support information about your VAIO computer.

1. Printed Documentation

- **Quick Start Guide** — An overview of components connection, set-up information, etc.
- **Troubleshooting and Recovery Guide**
- **Regulations, Guarantee, EULA and Service Support**

2. On-screen Documentation

- **User Guide** (This manual) — Features of your computer and information about solving common problems.

  To view this on-screen guide:

  1. Double-click the **VAIO User Guide** icon on the desktop.
  2. Open the folder for your language.
  3. Select the guide you want to read.

  ✍
  You can manually browse to the user guides by going to **Computer** > **VAIO (C:)** (your C drive) > **Documentation** > **Documentation** and opening the folder for your language.

- **Windows Help and Support** — A comprehensive resource for practical advice, tutorials, and demonstrations to help you learn to use your computer.

  To access **Windows Help and Support**, click **Start** and **Help and Support**, or press and hold the Microsoft Windows key and press the **F1** key.

Downloaded from LpManual.com Manuals

3. Support Web Sites

If you have any problem with the computer, you can visit the VAIO-Link web site at http://www.vaio-link.com for troubleshooting.

Before contacting VAIO-Link by telephone, try to solve the problem by reading the supplied documentation and visiting other Sony web sites.

- For more about VAIO and becoming part of the growing VAIO community, visit the web site at http://www.club-vaio.com.
- For online purchases, visit the web site at http://www.sonystyle-europe.com.
- For other Sony products, visit the web site at http://www.sony.net.

When you contact VAIO-Link by telephone, have the serial number of your VAIO computer ready at hand. The serial number is located on the bottom, the back panel, or inside the battery compartment of your VAIO computer.

Downloaded from LpManual.com Manuals

Ergonomic Considerations

You will be using your computer as a portable device in a variety of environments. Whenever possible, you should attempt to take account of the following ergonomic considerations for both stationary and portable environments:



- **Position of your computer** – Place the computer directly in front of you (1). Keep your forearms horizontal (2), with your wrists in a neutral, comfortable position (3) while using the keyboard or the pointing device. Let your upper arms hang naturally at your sides. Take frequent breaks while using your computer. Excessive use of the computer may strain eyes, muscles, or tendons.
- **Furniture and posture** – Sit in a chair with good back support. Adjust the level of the chair so your feet are flat on the floor. A footrest may make you more comfortable. Sit in a relaxed, upright posture and avoid slouching forward or leaning far backwards.

Downloaded from LpManual.com Manuals

- **Viewing angle of the computer's display** – Use the display's tilting feature to find the best position. You can reduce eye strain and muscle fatigue by adjusting the tilt of the display to the proper position. Adjust the brightness level of the display as well.
- **Lighting** – Choose a location where windows and lights do not cause glare and reflection on the display. Use indirect lighting to avoid bright spots on the display. Proper lighting adds to your comfort and work efficiency.
- **Positioning an external display** – When using an external display, set the display at a comfortable viewing distance. Make sure the display screen is at eye level or slightly lower when you are sitting in front of the monitor.

Downloaded from LpManual.com Manuals

Getting Started

This section describes how to get started using your VAIO computer.

❑ **Locating Controls and Ports (page 10)**
❑ **About the Indicator Lights (page 17)**
❑ **Connecting a Power Source (page 18)**
❑ **Using the Battery Pack (page 19)**
❑ **Shutting Down Your Computer Safely (page 26)**
❑ **Updating Your Computer (page 27)**

Downloaded from LpManual.com Manuals

Locating Controls and Ports

Take a moment to identify the controls and ports shown on the following pages.

!
The appearance of your computer may be different from those illustrated in this manual due to variations in specifications. It may also vary in some countries or areas.

Downloaded from LpManual.com Manuals

Front



1 Built-in microphone (monaural)*1
2 Built-in **MOTION EYE** camera indicator*1 (page 17)
3 Built-in **MOTION EYE** camera*1 (page 33)
4 LCD screen (page 144)
5 Built-in speakers (stereo)
6 Keyboard (page 29)
7 Touch pad (page 31)
8 Headphones jack (page 94)
9 Microphone jack (page 104)
10 Memory Stick slot*2 (page 43)
11 Media Access indicator (page 17)
12 **SD** memory card slot (page 52)
13 Charge indicator (page 17)
14 Disc drive indicator (page 17)
15 **WIRELESS** indicator (page 17)

*1 On selected models only.

*2 Your computer supports both the standard-size Memory Stick and the Duo-size Memory Stick.

Downloaded from LpManual.com Manuals



1 **WIRELESS** switch (page 60), (page 68)
2 Muting button (page 32)
3 **S1** button (page 32)
4 Num lock indicator (page 17)
5 Caps lock indicator (page 17)
6 Scroll lock indicator (page 17)
7 Fingerprint sensor* (page 73)

* On selected models only.

Downloaded from LpManual.com Manuals

Back



1 Battery connector (page 19)

Downloaded from LpManual.com Manuals

Right



1 i.LINK 4-pin (S400) port (page 107)
2 Hi-Speed USB (USB 2.0) ports* (page 105)
3 Optical disc drive (page 35)
4 Optical disc drive indicator (page 17)
5 Drive eject button (page 35)
6 Manual eject hole (page 182)
7 Network (Ethernet) port (page 58)
8 Modem port (page 56)
9 Power button/Power indicator (page 17)

* Support high-/full-/low- speeds.

Downloaded from LpManual.com Manuals

Left



1 **DC IN** port (page 18)
2 Security slot
3 Air vent
4 Monitor port*1 (page 96)
5 Hi-Speed USB (USB 2.0) port*2 (page 105)
6 PC Card slot (page 49)
7 PC Card release button (page 51)

*1 Not accessible when your computer is attached to the docking station.

*2 Supports high-/full-/low- speeds.

Downloaded from LpManual.com Manuals

Bottom



1 Memory module compartment cover (page 137)
2 Air vents
3 Docking station connector (page 88)

Downloaded from LpManual.com Manuals

About the Indicator Lights

Your computer is equipped with the following indicator lights:

Indicator	Functions
Power	Illuminates in green when the computer is on, blinks slowly in orange while the computer is in Sleep mode, and turns off when the computer is off or in Hibernate mode.
Charge	Illuminates while the battery pack is charging. See **Charging the Battery Pack** (page 22) for more information.
Media Access	Illuminates while data is being read from or written to a memory card, such as the Memory Stick and the SD memory card. (Do not place the computer into Sleep mode or turn it off when this indicator is lit.) When the indicator is unlit, the memory card is not in use.
Built-in **MOTION EYE** camera*	Illuminates while the built-in camera is in use.
Optical disc drive	Illuminates while the drive is reading or writing data. When the indicator is unlit, the optical disc media is not in use.
Disc drive	Illuminates while the built-in storage device or the optical disc drive is running to read or write data. Do not place the computer into Sleep mode or turn it off when this indicator is lit.
Num lock	Press the **Num Lk** key to activate the numeric keypad. Press it a second time to deactivate the numeric keypad. The numeric keypad is not active when the indicator is unlit.
Caps lock	Press the **Caps Lock** key to type letters in uppercase. Letters appear in lowercase if you press the **Shift** key while the indicator is lit. Press the key a second time to turn off the indicator. Normal typing resumes when the Caps lock indicator is unlit.
Scroll lock	Press the **Fn**+**Scr Lk** keys to change how you scroll the display. Normal scrolling resumes when the Scroll lock indicator is unlit. The **Scr Lk** key functions differently depending on the program you are using and does not work with all programs.
WIRELESS	Illuminates when one or more wireless options are enabled.

* On selected models only.

Downloaded from LpManual.com Manuals

Connecting a Power Source

You can use either an AC adapter or a rechargeable battery pack for supplying power to your computer.

Using the AC Adapter

Use only the supplied AC adapter for your computer.

To use the AC adapter

1 Plug one end of the power cord (1) into the AC adapter (3).

2 Plug the other end of the power cord into an AC outlet (2).

3 Plug the cable connected to the AC adapter (3) into the **DC IN** port (4) on the computer or on the optional docking station.



To disconnect your computer completely from AC power, unplug the AC adapter.

Make sure that the AC outlet is easily accessible.

If you do not intend to use your computer for a long period of time, place the computer into Hibernate mode. See **Using Hibernate Mode** **(page 126)**.

Downloaded from LpManual.com Manuals

Using the Battery Pack

The battery pack supplied with your computer is not fully charged at the time of delivery.

Installing the Battery Pack

To install the battery pack

1 Turn off the computer and close the LCD screen lid.

2 Slide the battery **LOCK** switch (1) inward.



Downloaded from LpManual.com Manuals

3 Slide the battery pack diagonally into the battery compartment until the projections (2) on either side of the battery compartment fit into the U-shaped cuts (3) on either side of the battery pack.



Downloaded from LpManual.com Manuals

4 Push the battery pack down into the compartment until it clicks into place.



5 Slide the battery **LOCK** switch outward to secure the battery pack on the computer.

When your computer is directly connected to AC power and has a battery pack installed, it uses power from the AC outlet.

Certain rechargeable batteries do not meet Sony quality and safety standards. For safety reasons this computer only functions with genuine Sony battery packs designed for this model. If an unauthorized battery pack is installed, the battery will not be charged and the computer will not function.

Downloaded from LpManual.com Manuals

Charging the Battery Pack

The battery pack supplied with your computer is not fully charged at the time of delivery.

To charge the battery pack

1 Install the battery pack.

2 Connect the computer to a power source with the AC adapter.
The charge indicator light turns on while the battery pack is charging. When the battery pack charges close to the maximum charge level you selected with the battery charge functions, the charge indicator turns off. To select your desired maximum charge level, see **Using the Battery Charge Functions** **(page 24)**.

Charge indicator status	Meaning
Lit in orange	The battery pack is charging.
Blinks along with the green power indicator	The battery pack is running out of power. (Normal mode)
Blinks along with the orange power indicator	The battery pack is running out of power. (Sleep mode)
Blinks fast in orange	A battery error has occurred due to a failed battery pack or an unlocked battery pack.

!
Charge the battery pack as described in this manual from your first battery charge.

Downloaded from LpManual.com Manuals

✍
Keep the battery pack in your computer while it is directly connected to AC power. The battery pack continues to charge while you are using the computer.

If the battery charge level falls below 10%, you should either connect the AC adapter to recharge the battery pack or shut down your computer and install a fully charged battery pack.

Your computer is supplied with a lithium ion battery pack and can be recharged any time. Charging a partially discharged battery pack does not affect the life of battery.

While some software applications or peripheral devices are in use, your computer may not enter Hibernate mode even when the remaining battery life is short. To avoid loss of data when using battery power, you should save your data frequently and manually activate a power management mode, such as Sleep or Hibernate.

If the battery pack wears out when the computer enters Sleep mode, you will lose all unsaved data. Going back to the previous work state is impossible. To avoid loss of data, you should save your data frequently.

When your computer is directly connected to AC power and has a battery pack installed, it uses power from the AC outlet.

Downloaded from LpManual.com Manuals

Using the Battery Charge Functions

You can customize the current battery charging method using the **Battery Charge Functions**. To make the life of battery longer, enable the battery care function.

To enable the battery care function

1. Click **Start**, **All Programs**, and **VAIO Control Center**.
2. Click **Power Management** and then **Battery Charge Functions**.
3. Click **Advanced**.
4. Click to select the **Enable Battery Care Function** check box.
5. Select the desired maximum charge level.
6. Click **OK**.

To check the battery charge capacity

Follow steps 1 to 3 in **To enable the battery care function** above and check detailed information. If the battery charge capacity is low, replace the battery pack with a new genuine Sony battery pack.

Using the Battery Life Conserving Wallpaper

You can conserve your battery life just by setting the specific wallpaper as your desktop background.

To set the battery life conserving wallpaper

1. Click **Start**, **All Programs**, and **VAIO Control Center**.
2. Click **Display** and then **Long Battery Life Wallpaper Setting**.
3. Click **Set Long Battery Life Wallpaper**.
   At the confirmation prompt, click **OK**.

Downloaded from LpManual.com Manuals

Removing the Battery Pack

!
You may lose data if you remove the battery pack while your computer is on and not connected to the AC adapter or if you remove the battery pack while the computer is in Sleep mode.

To remove the battery pack

1 Turn off the computer and close the LCD screen lid.

2 Slide the battery **LOCK** switch (1) inward.

3 Slide and hold the battery **RELEASE** latch (2) inward, put your fingertip underneath the tab (3) on the battery pack, and lift the battery pack in the direction of the arrow, and then slide it away from the computer.



Downloaded from LpManual.com Manuals

Shutting Down Your Computer Safely

To avoid losing unsaved data, be sure to shut down your computer properly, as described below.

To shut down your computer

1 Turn off any peripherals connected to the computer.

2 Click **Start**, the arrow next to the **Lock** button, and then **Shut Down**.

3 Respond to any prompts warning you to save documents or to consider other users and wait for the computer to turn off automatically.
The power indicator light turns off.

Downloaded from LpManual.com Manuals

Updating Your Computer

Be sure to install the latest updates on your computer with the following software applications so that the computer can run more efficiently.

- **Windows Update**
  Click **Start**, **All Programs**, and **Windows Update** and then follow the on-screen instructions.
- **VAIO Update 4**
  Click **Start**, **All Programs**, **VAIO Update 4**, and **VAIO Update Options** and then follow the on-screen instructions.

  !
  Your computer must be connected to the Internet to download the updates.

Downloaded from LpManual.com Manuals

Using Your VAIO Computer

This section describes how to get the most out of using your VAIO computer.

❑ **Using the Keyboard (page 29)**
❑ **Using the Touch Pad (page 31)**
❑ **Using Special-function Buttons (page 32)**
❑ **Using the Built-in Camera (page 33)**
❑ **Using the Optical Disc Drive (page 35)**
❑ **Using the Memory Stick (page 43)**
❑ **Using Other Modules / Memory Cards (page 49)**
❑ **Using the Internet (page 56)**
❑ **Using the Network (LAN) (page 58)**
❑ **Using the Wireless LAN (page 60)**
❑ **Using the Bluetooth Function (page 68)**
❑ **Using Fingerprint Authentication (page 73)**
❑ **Using the TPM (page 80)**

Downloaded from LpManual.com Manuals

Using the Keyboard

Your keyboard has additional keys that perform model-specific tasks.

Combinations and Functions with the Fn Key

Some keyboard functions can be used only after the operating system is finished launching.

Combinations/Feature	Functions
Fn + **(F3/F4)**: speaker volume	Changes the built-in speaker volume level. To increase the volume, keep pressing the **Fn**+**F4** keys or press the **Fn**+**F4** keys and then the ↑ or → key. To decrease the volume, keep pressing the **Fn**+**F3** keys or press the **Fn**+**F3** keys and then the ↓ or ← key.
Fn + **(F5/F6)**: brightness control	Changes the LCD brightness of your computer screen. To increase lighting intensity, keep pressing the **Fn**+**F6** keys or press the **Fn**+**F6** keys and then the ↑ or → key. To decrease lighting intensity, keep pressing the **Fn**+**F5** keys or press the **Fn**+**F5** keys and then the ↓ or ← key.
Fn + LCD/ **(F7)**: display output	Toggles among your computer screen, an external display, and simultaneous output to both.
Fn + / **(F9/F10)**: zoom	Changes the size of an image or a document displayed on some software. To make the view look smaller and further away (zoom out), press the **Fn+F9** keys. To make the view look bigger and closer (zoom in), press the **Fn+F10** keys. See the help file included with the **VAIO Control Center** for more information.

Downloaded from LpManual.com Manuals

Combinations/Feature	Functions
Fn + **(F12)**: hibernate	Provides the lowest level of power consumption. When you execute this command, the states of the system and the connected peripheral devices are saved to the built-in storage device and the system power is turned off. To return the system to its original state, use the power button to turn on the power. For details on power management, see **Using the Power Saving Modes** (page 123).

Downloaded from LpManual.com Manuals

Using the Touch Pad

You can point to, select, drag, and scroll objects on the screen using the touch pad.



Action	Description
Point	Slide your finger on the touch pad (1) to place the pointer (2) on an item or object.
Click	Press the left button (3) once.
Double-click	Press the left button twice in a row.
Right-click	Press the right button (4) once. In many applications, this action displays a shortcut menu.
Drag	Slide your finger on the touch pad while pressing the left button.
Scroll	Slide your finger along the right edge of the touch pad to scroll vertically. Slide your finger along the bottom edge to scroll horizontally (the scroll function is available only with applications that support a touch pad scroll feature).

✍ You can disable/enable the touch pad while a mouse is connected to your computer. To change the touch pad settings, use the **VAIO Control Center**.

! Be sure to connect a mouse before disabling the touch pad. If you disable the touch pad before connecting a mouse, you will be able to use only the keyboard for pointer operations.

Downloaded from LpManual.com Manuals

Using Special-function Buttons

Your computer is equipped with special buttons to help you use specific functions of the computer.

Special-function button	Functions
Muting button	Turns the volume on and off.
S1 button	By default, the **S1** button places your computer into Presentation mode as indicated by the **P** mark. In Presentation mode, some functions of the computer that may disturb a presentation are disabled, such as a screen saver, the power saving modes, and system message generation. To bring the computer back into Normal mode, press this button once again. You can change the default assignment with the **VAIO Control Center**. To change the Presentation mode settings, click **Start**, **Control Panel**, **Mobile PC**, and **Adjust settings before giving a presentation** under **Windows Mobility Center**, and change the settings in the **Presentation Settings** window.

Downloaded from LpManual.com Manuals

Using the Built-in Camera

Your computer may be equipped with a built-in **MOTION EYE** camera.

Features and options in this section may not be available on your computer.
See the specifications to find out about the configuration of your computer.

With the preinstalled image capture software, you can perform the following operations:

- Capturing still images and movies
- Sensing and capturing object movements for monitoring purposes
- Editing captured data

Turning on the computer activates the built-in camera.

Video conference is possible with the appropriate software.

Launching or exiting your instant messaging or video editing software does not activate or deactivate the built-in camera.

Do not place your computer into Sleep or Hibernate mode while you are using the built-in camera.

You cannot operate the built-in camera with the **Microsoft Windows Movie Maker** software.

Downloaded from LpManual.com Manuals

To use the preinstalled image capture software

1 Click **Start**, **All Programs**, **ArcSoft WebCam Companion 2**, and **WebCam Companion 2**.

2 Click the desired icon in the main window.
For detailed information on how to use the software, see the help file included with the software.

✍
When capturing an image or a movie in a dark place, click the **Capture** icon or the **Record** icon in the main window, and then click the **WebCam Settings** icon and select the low light or low light compensation option in the properties window.

Downloaded from LpManual.com Manuals

Using the Optical Disc Drive

Your computer is equipped with an optical disc drive.

!
You cannot use optical discs if you disable the optical disc drive in the BIOS setup screen. To enable the drive, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

Features and options in this section may not be available on your computer.
See the specifications to find out about the configuration of your computer.

Downloaded from LpManual.com Manuals

To insert a disc

1 Turn on the computer.

2 Press the drive eject button (1) to open the drive.
The drive tray slides out.

3 Place a disc in the middle of the drive tray with the label side facing upward and gently push it down until the disc clicks into place.



!
Do not exert pressure on the drive tray. Be sure to hold the bottom of the drive tray when placing/removing a disc onto/from the tray.

Downloaded from LpManual.com Manuals

4 Close the drive tray by pushing it in gently.

!
Do not remove the optical disc when your computer is in a power saving mode (Sleep or Hibernate). Be sure to bring the computer back into Normal mode before removing the disc.

Downloaded from LpManual.com Manuals

Supported Disc Media

Your computer plays and records CDs, DVDs, and Blu-ray Disc™ media, depending on the model you purchased. See the reference chart below to find out which type of optical disc drive supports which types of media.

PR: playable and recordable
P: playable but not recordable
–: not playable or recordable

	CD-ROM	Video CD	Music CD	CD Extra	CD-R/RW	DVD-ROM	DVD-Video	DVD-R/RW	DVD+R/RW	DVD+R DL (Double Layer)	DVD-R DL (Dual Layer)	DVD-RAM*1 *2	BD-ROM	BD-R/RE*3
DVD±RW/±R DL/RAM	P	P	P	P	PR	P	P	PR	PR	PR	PR	PR	–	–
Blu-ray Disc	P	P	P	P	PR	P	P	PR	PR	PR	PR	PR	P	PR*4
Blu-ray Disc Combo	P	P	P	P	PR*5	P	P	PR	PR	PR	PR	PR	P	P

*1 The DVD±RW/RAM disc drive on your computer does not support the DVD-RAM cartridge. Use non-cartridge discs or discs with a removable cartridge.

*2 Writing data to single-sided DVD-RAM discs (2.6 GB) compliant with DVD-RAM Version 1.0 is not supported.
DVD-RAM Version 2.2/12X-SPEED DVD-RAM Revision 5.0 disc is not supported.

*3 The Blu-ray Disc drive on your computer does not support BD-RE Disc media in Version 1.0 format and Blu-ray Disc media with a cartridge.

*4 Supports writing data to BD-R Version 1.1/1.2/1.3 discs (single-layer discs with the capacity of 25 GB, dual-layer discs with the capacity of 50 GB) and BD-RE Version 2.1 discs (single-layer discs with the capacity of 25 GB, dual-layer discs with the capacity of 50 GB).

*5 Writing data to Ultra Speed CD-RW discs is not supported.

Downloaded from LpManual.com Manuals

!
This product is designed to play back discs that conform to the Compact Disc Digital Audio standard specifications (CD Standard). A DualDisc is a two sided disc product which mates DVD recorded material on one side with digital audio material on the other side. Be aware that the audio side (non-DVD side) of a DualDisc may not play on this product because it does not conform to the CD Standard.

When you buy pre-recorded or blank discs for use with your VAIO computer, be sure to read the notices on the disc package carefully to check both playback and recording compatibility with your computer's optical disc drives. Sony does NOT guarantee the compatibility of VAIO optical disc drives with discs that are not compliant with the official "CD," "DVD," or "Blu-ray Disc" standard. USING NON-COMPLIANT DISCS CAN CAUSE FATAL DAMAGE TO YOUR VAIO PC OR CREATE SOFTWARE CONFLICTS AND CAUSE SYSTEM HANGING.
For inquiries about disc formats, contact the individual publisher of the pre-recorded disc or the manufacturer of the recordable disc.

✍
8 cm disc writing is not supported.

!
To play copyright protected Blu-ray Disc media continually, update the AACS key. The AACS key update requires Internet access.

As with other optical media devices, circumstances may limit compatibility or prevent Blu-ray Disc media playback. VAIO computers may not support movie playback on packaged media recorded in AVC or VC1 formats at high bit rates.

Region settings are required for some contents on DVD and BD-ROM Disc media. If the region setting on the optical disc drive does not match the region coding on the disc, playback is not possible.

Unless your external display is compliant with the High-bandwidth Digital Content Protection (HDCP) standard, you cannot play or view the contents on copyright protected Blu-ray Disc media.

Some contents may restrict video output to standard definition or prohibit analog video output. It is strongly recommended that a digital HDCP compliant environment be implemented for optimum compatibility and viewing quality.

Do not use memory-resident utility software when playing or writing a disc. This may cause the computer to malfunction.

Downloaded from LpManual.com Manuals

Notes on Using the Optical Disc Drive

Notes on writing data to a disc

- Only use circular discs. Do not use discs in any other shape (star, heart, card, etc.), as this may damage the optical disc drive.
- Do not strike or shake your computer while the optical disc drive is writing data to a disc.
- Do not plug or unplug the AC adapter while the optical disc drive is writing data to a disc.

Notes on playing discs

To achieve optimum performance when playing discs, you should follow these recommendations:

- Some CD players and computer optical disc drives may not be able to play audio CDs created with the CD-R or CD-RW media.
- Some DVD players and computer optical disc drives may not be able to play DVDs created with the DVD+R DL, DVD-R DL, DVD+R, DVD+RW, DVD-R, DVD-RW, or DVD-RAM media.
- Depending on system environment, you may find sound interruptions and/or dropped frames during AVC HD playback.
- Do not place your computer into either of the power saving modes while your computer is playing a disc.

Downloaded from LpManual.com Manuals

Notes on region codes

- Region code indicators are labeled on the discs or packages to indicate in which region and on what type of player you can play the disc. Unless the region code indicates "2" (Europe belongs to region "2"), "5" (Russia belongs to region "5"), or "all" (this means that you can play this disc in most regions of the world), you cannot play the disc on your computer.

  !
  If you change the region code while the **WinDVD** or **WinDVD BD** software is running, restart the software or eject the disc and re-insert it to make the new setting effective.

- Do not try to change the region code settings of the drive. Any difficulties caused by changing the region code settings of the drive are not covered by the warranty.

Downloaded from LpManual.com Manuals

Playing Discs

To play a disc

1 Insert a disc into the optical disc drive.

! Connect the AC adapter to the computer and close all running software applications before playing a disc.

2 If nothing appears on the desktop, click **Start**, **All Programs**, and the desired software to play the disc.
For instructions on how to use the software, see the help file included with the software.

Copying Files to Discs

To copy files to a disc

1 Insert a recordable disc into the optical disc drive.

! Connect the AC adapter to the computer and close all running software applications before copying files to a disc.

2 If nothing appears on the desktop, click **Start**, **All Programs**, and the desired disc burning software to copy files to the disc.
For instructions on how to use the software, see the help file included with the software.

Downloaded from LpManual.com Manuals

Using the Memory Stick

The Memory Stick is a compact, portable, and versatile IC recording media especially designed for exchanging and sharing digital data with compatible products, such as digital cameras, mobile phones, and other devices. Because it is removable, it can be used for external data storage.

!
You cannot use the Memory Stick if you disable the Memory Stick slot in the BIOS setup screen. To enable the slot, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

Before You Use the Memory Stick

The Memory Stick slot on your computer can accommodate both standard- and Duo-size media and supports Memory Stick PRO, Memory Stick PRO Duo, and Memory Stick PRO-HG Duo with high-speed data transfer and large data capacity capabilities.

For the latest information about the Memory Stick, visit the Memory Stick web site at http://www.memorystick.com/en/.

Downloaded from LpManual.com Manuals

Inserting and Removing a Memory Stick

To insert a Memory Stick

1 Locate the Memory Stick slot.

2 Hold the Memory Stick with the arrow facing upward and pointing toward the slot.

3 Carefully slide the Memory Stick into the slot until it clicks into place.

The Memory Stick is automatically detected by your system and the contents on the Memory Stick are displayed. If nothing appears on the desktop, click **Start**, **Computer**, and double-click the Memory Stick icon.



You can insert a Duo-size Memory Stick directly into the Memory Stick slot without using a Memory Stick Duo adaptor.

Downloaded from Upmanuals.com

!
Be sure to hold the Memory Stick with the arrow pointing in the correct direction as you insert it into the slot. To avoid damaging your computer or the media, do not force the Memory Stick into the slot if you cannot insert it smoothly.

Before using a Memory Stick Micro (M2), be sure to insert it into an M2 Standard-size adaptor or M2 Duo adaptor. If you insert the media directly into the Memory Stick slot without the adaptor, you may not be able to remove it from the slot.

The Memory Stick Micro in an M2 Duo adaptor may not operate properly if it is additionally inserted into a Memory Stick Duo adaptor.

Downloaded from LpManual.com Manuals

To remove a Memory Stick

!
Do not remove the Memory Stick while the Media Access indicator light is lit. If you do, you may lose data. Large volumes of data may take time to load, so make sure the indicator is unlit before removing the Memory Stick.

1. Check that the Media Access indicator light is unlit.
2. Push in the Memory Stick toward the computer and release.
   The Memory Stick ejects.
3. Pull the Memory Stick out of the slot.

!
Always remove the Memory Stick gently, or it may pop out unexpectedly.

Downloaded from LpManual.com Manuals

Formatting a Memory Stick

To format a Memory Stick

The Memory Stick has been formatted in the factory default setting and is ready for use.
If you want to reformat the media with your computer, follow these steps.

!
Be sure to use the device that is designed to format the media and supports the Memory Stick when formatting the media.

Formatting the Memory Stick erases the entire data on the media. Before formatting the media, make sure that it does not contain your valuable data.

Do not remove the Memory Stick from the slot while formatting. This could cause a malfunction.

1 Carefully slide the Memory Stick into the slot until it clicks into place.

2 Click **Start** and **Computer** to open the **Computer** window.

3 Right-click the Memory Stick icon and select **Format**.

4 Click **Restore device defaults**.

!
The size of the allocation unit and file system may change.

Do not select **NTFS** from the **File system** drop-down list as it may cause a malfunction.

The formatting process will be completed more quickly if you select **Quick Format** in **Format options**.

5 Click **Start**.

6 Follow the on-screen instructions.

!
It may take time to format the Memory Stick depending on the media type.

Downloaded from LpManual.com Manuals

Notes on Using the Memory Stick

- Your computer has been tested and found compatible with Sony branded Memory Stick with capacity of up to 16 GB that are available as of January 2009. However, not all the Memory Stick that meet the same specifications as the compatible media are guaranteed of compatibility.
- Inserting a Memory Stick with multiple conversion adaptors is not guaranteed of compatibility.
- MagicGate is the general name of the copyright protection technology developed by Sony. Use a Memory Stick with the MagicGate logo to use this feature.
- Except for your personal use, it is against the copyright law to use any audio and/or image data you recorded without prior consent from the respective copyright holders. Accordingly, the Memory Stick with such copyrighted data can be used only within the law.
- The Memory Stick slot on your computer does not support 8-bit parallel data transfer (high-speed data transfer).
- Do not insert more than one Memory Stick into the slot. Improper insertion of the media may damage both your computer and the media.

Downloaded from LpManual.com Manuals

Using Other Modules / Memory Cards

Using the PC Card

PC Cards allow you to connect portable external devices to your computer.

!
You cannot use PC Cards if you disable the PC Card slot in the BIOS setup screen. To enable the slot, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

Downloaded from LpManual.com Manuals

To insert a PC Card

!
Some PC Cards or their functions may not be compatible with your computer.



Some devices may not function properly if you continuously switch to Normal mode from Sleep or Hibernate mode. For some PC Cards, if you alternate between Normal mode and Sleep or Hibernate mode while the card is inserted, you may find that the device connected to your system through the PC Card is not recognized. Restart your system to correct the problem.

While the card is inserted, your computer may not enter Hibernate mode but Sleep mode. We recommend that you remove the card if you want the computer to enter Hibernate mode.

Make sure you use the latest software driver provided by the PC Card manufacturer.

Do not force a PC Card into the slot. It may damage the connector pins. If you have difficulty inserting a PC Card, check that you are inserting the PC Card in the correct direction. See the manual that came with your PC Card for more information.

Downloaded from LpManual.com Manuals

To remove a PC Card

✍
To remove the PC Card when your computer is off, skip steps 1 to 4.

1. Double-click the **Safely Remove Hardware** icon on the taskbar.
2. Select the hardware you want to unplug.
3. Click **Stop**.
4. Follow the on-screen instructions to remove the PC Card.
5. Push the PC Card release button so that the release button pops out.
6. Push the PC Card release button a second time so that the PC Card pops out.
7. Gently take hold of the PC Card and pull it out of the slot.
8. If the PC Card release button is still out, push it back in all the way to the end.

Downloaded from LpManual.com Manuals

Using the SD Memory Card

Your computer is equipped with an **SD** memory card slot. You can use this slot to transfer data among digital cameras, camcorders, music players, and other audio/video devices.

!
You cannot use SD memory cards if you disable the SD memory card slot in the BIOS setup screen. To enable the slot, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

Before you use the SD memory card

The **SD** memory card slot on your computer supports the following memory cards:

- SD memory card
- SDHC memory card
- MultiMediaCard (MMC)

For the latest information on compatible memory cards, see **Finding More about Your VAIO Computer** **(page 5)** to visit the appropriate support web site.

Downloaded from LpManual.com Manuals

To insert an SD memory card

1 Locate the **SD** memory card slot.

2 Hold the SD memory card with the arrow facing upward and pointing toward the slot.

3 Carefully slide the SD memory card into the slot until it clicks into place.
Do not force the card into the slot.



If the SD memory card does not go into the slot easily, remove it gently and verify you are inserting it in the proper direction.

Downloaded from LpManual.com Manuals

To remove an SD memory card

1. Check that the Media Access indicator light is unlit.
2. Push in the SD memory card toward the computer and release.
   The SD memory card ejects.
3. Pull the SD memory card out of the slot.

Downloaded from LpManual.com Manuals

Notes on Using Memory Cards

General notes on using the memory card

- Be sure to use memory cards that are compliant with the standards supported by your computer.
- Be sure to hold the memory card with the arrow pointing in the correct direction as you insert it into the slot. To avoid damaging your computer or the media, do not force the memory card into the slot if you cannot insert it smoothly.
- Use care when inserting or removing the memory card from the slot. Do not force it in or out of the slot.
- Do not remove the memory card while the media access indicator light is lit. If you do, you may lose data.
- Do not attempt to insert an memory card or memory card adaptor of a different type into the memory card slot. An incompatible memory card or memory card adaptor may cause difficulty in removing from the slot and can cause damage to your computer.

Notes on using the SD memory card

- Your computer has been tested and found compatible only with major memory cards available as of January 2009. However, not all memory cards that meet the same specifications as the compatible media are guaranteed of compatibility.
- SD memory cards with capacity of up to 2 GB and SDHC memory cards with capacity of up to 32 GB have been tested and found compatible with your computer.
- The SD memory card slot on your computer does not support the high-speed data transfer feature of the SD memory card and the SDHC memory card.

Downloaded from LpManual.com Manuals

Using the Internet

Before using the Internet, you need to sign up with an Internet Service Provider (ISP) and set up devices required for connecting your computer to the Internet.

The following types of Internet connection services may be available from your ISP:

- Fiber to the Home (FTTH)
- Digital Subscriber Line (DSL)
- Cable modem
- Satellite
- Dial-up

For detailed information on devices required for the Internet and how to connect your computer to the Internet, ask your ISP.

✍
To connect your computer to the Internet using the wireless LAN function, you need to set up the wireless LAN network. See **Using the Wireless LAN (page 60)** for more information.

!
When you connect your computer to the Internet, be sure to take appropriate security measures to protect the computer against online threats.

If your computer is not equipped with a built-in modem, you may need to connect an external modem device, for example a USB telephone modem, a DSL modem, or a cable modem, to your computer. For the detailed instructions on connection setups and modem configuration, see the manual that came with your modem.

Downloaded from LpManual.com Manuals

To connect a telephone cable

!
The following procedure applies to models with a built-in modem only.

1 Plug one end of the phone cable (1) into the modem port on the computer.

2 Plug the other end into the wall jack (2).



!
Your computer does not work with party lines, cannot be connected to a coin-operated telephone, and may not work with multiple telephone lines or a private branch exchange (PBX). Some of these connections may result in excess electrical current and could cause a malfunction in the built-in modem.

If you connect a telephone cable coming through a splitter, the modem or connected device may not work properly.

To set up a dial-up connection to the Internet

!
The following procedure applies to models with a built-in modem only.

1 Click **Start** and **Control Panel**.

2 Click **Connect to the Internet** under **Network and Internet**.
The **Connect to the Internet** window appears.

3 Click **Dial-up**.

4 Follow the on-screen instructions.

Downloaded from LpManual.com Manuals

Using the Network (LAN)

You can connect your computer to 1000BASE-T/100BASE-TX/10BASE-T type networks with an Ethernet network cable. Connect one end of a network cable (not supplied) to the network (Ethernet) port on the computer or the optional docking station and the other end to your network. For detailed settings and devices needed to connect to the network, ask your network administrator.

!
You cannot access Ethernet networks if you disable the network (Ethernet) port in the BIOS setup screen. To enable the port, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.



✍
Your computer can be connected to the network with the default settings.

When your computer is attached to the optional docking station, you need to select which network (Ethernet) port to use. Follow the on-screen instructions.

Downloaded from LpManual.com Manuals

!
Do not plug a telephone cable into the network (Ethernet) port on your computer.
If the network (Ethernet) port is connected to one of the telephone lines mentioned below, high electric current to the port may cause damage, overheating, or fire.

- Home (intercom speakerphone) or business-use telephone lines (multi-line business telephone)
- Public telephone subscriber line
- Private branch exchange (PBX)

Downloaded from LpManual.com Manuals

Using the Wireless LAN

Using the Wireless LAN (WLAN), all your digital devices with the built-in WLAN function communicate freely with each other through a network. A WLAN is a network in which a user can connect to a Local Area Network (LAN) through a wireless (radio) connection.

!
You cannot access wireless networks if you disable the wireless LAN function in the BIOS setup screen. To enable the function, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

The WLAN supports all normal Ethernet connectivity, but with the added benefits of mobility and roaming. You can still access information, Internet/intranet and network resources, even in the middle of a meeting, or as you move from one place to another.

You can communicate without an access point, which means that you can communicate with a limited number of computers (ad-hoc). Or you can communicate through an access point, which allows you to create a full infrastructure network.

Downloaded from LpManual.com Manuals

In some countries, using WLAN products may be restricted by the local regulations (e.g. limited number of channels). Therefore, before activating the WLAN function, read the wireless LAN regulations guide carefully.

WLAN uses the IEEE 802.11a*/b/g standard or the IEEE 802.11n* draft standard, which specifies the type of technology used. The standard includes the encryption methods: Wired Equivalent Privacy (WEP), which is a security protocol, Wi-Fi Protected Access 2 (WPA2), and Wi-Fi Protected Access (WPA). Proposed jointly by the IEEE and Wi-Fi Alliance, both WPA2 and WPA are specifications of standards based on interoperable security enhancements that increase the level of data protection and access control for existing Wi-Fi networks. WPA is designed to be forward compatible with the IEEE 802.11i specification. It utilizes the enhanced data encryption Temporal Key Integrity Protocol (TKIP) in addition to user authentication using 802.1X and Extensible Authentication Protocol (EAP). Data encryption protects the vulnerable wireless link between clients and access points. Besides that, there are other typical LAN security mechanisms to ensure privacy, such as: password protection, end-to-end encryption, virtual private networks, and authentication. WPA2, the second generation of WPA, provides stronger data protection and network access control and is also designed to secure all versions of 802.11 devices, including 802.11b, 802.11a, 802.11g, and 802.11n draft standard, multi-band and multi-mode. In addition, based on the ratified IEEE 802.11i standard, WPA2 provides government grade security by implementing the National Institute of Standards and Technology (NIST) FIPS 140-2 compliant AES encryption algorithm and 802.1X-based authentication. WPA2 is backward compatible with WPA.

* See the specifications to find out about the configuration of your computer.

The IEEE 802.11b/g standard is a wireless LAN standard, using the 2.4 GHz band. The IEEE 802.11g standard provides higher-speed communications than the IEEE 802.11b standard.

The IEEE 802.11a standard is a wireless LAN standard, using the 5 GHz band.

The IEEE 802.11n draft standard is a wireless LAN standard, using the 2.4 GHz or 5 GHz band.

Wireless LAN devices using the 2.4 GHz band cannot communicate with devices using the 5 GHz band because the frequencies are different.

The 2.4 GHz band used by wireless LAN compatible devices is also used by other various devices. Although technologies to minimize interference from other devices that use the same band are employed on wireless LAN compatible devices, such interference may cause lower communication speed, narrower communication range, or broken wireless connections.

Downloaded from LpManual.com Manuals

The communication speed varies depending on the distance between communication devices, existence of obstacles between such devices, the device configuration, the radio conditions, and the software in use. In addition, communications may be cut off depending on the radio conditions.

The communication range varies depending on the actual distance between communication devices, existence of obstacles between such devices, the radio conditions, the ambient environment that includes existence of walls and materials of such walls, and the software in use.

Actual communication speed may not be as fast as the one displayed on your computer.

Deploying IEEE 802.11b and IEEE 802.11g products on the same wireless network may reduce the communication speed due to radio interference. Taking this into consideration, the IEEE 802.11g products are designed to reduce the communication speed to ensure communications with IEEE 802.11b products. When the communication speed is not as fast as expected, changing the wireless channel on the access point may increase the communication speed.

Downloaded from LpManual.com Manuals

Communicating without an Access Point (Ad-hoc)

An ad-hoc network is a network in which a LAN is created only by wireless devices themselves, with no other central controller or access point. Each device communicates directly with other devices in the network. You can set up an ad-hoc network easily at home.



Downloaded from LpManual.com Manuals

To communicate without an access point (ad-hoc)

!
The IEEE 802.11a standard, using the 5 GHz band, and the IEEE 802.11n draft standard, using the 2.4 GHz or 5 GHz band, are not available on ad-hoc networks.

1. Turn on the **WIRELESS** switch.
2. Click the button next to or above your desired wireless option(s) in the **VAIO Smart Network** window.
   Make sure the **WIRELESS** indicator light turns on.
3. Click **Start** and **Control Panel**.
4. Click **View network status and tasks** under **Network and Internet**.
5. Click **Set up a connection or network** in the left pane.
   The **Set up a connection or network** window appears.
6. Select an option to specify the ad-hoc network settings and click **Next**.
7. Follow the on-screen instructions.

Downloaded from LpManual.com Manuals

Communicating with an Access Point (Infrastructure)

An infrastructure network is a network that extends an existing wired local network to wireless devices by providing an access point (not supplied). The access point bridges the wireless and wired LAN and acts as a central controller for the wireless LAN network. The access point coordinates transmission and reception from multiple wireless devices within a specific range.

The access point will select which channel to use on an infrastructure network.

! For details on how to select the channel that will be used by the access point, see the manual that came with your access point.



Downloaded from LpManual.com Manuals

To connect to a wireless network

1 Make sure an access point is set up.
See the manual that came with your access point for more information.

2 Turn on the **WIRELESS** switch.

3 Click the button next to or above your desired wireless option(s) in the **VAIO Smart Network** window.
Make sure the **WIRELESS** indicator light turns on.

!
Wireless LAN communication (IEEE 802.11a standard) using only the 5 GHz band, available on selected models only, is disabled by default. To enable 5 GHz band communication, you need to select the option to use the 5 GHz band or both the 2.4 GHz and 5 GHz bands on the **WLAN** tab in the **VAIO Smart Network** settings window.

4 Right-click or on the taskbar and select **Connect to a network**.

5 Select the desired access point and click **Connect**.

✍
For WPA-PSK or WPA2-PSK authentication, you must enter a passphrase. The passphrase is case sensitive and must be a text string between 8 and 63 characters in length or a hexadecimal string of 64 characters.

Downloaded from LpManual.com Manuals

Stopping Wireless LAN Communications

To stop wireless LAN communications

Click the button next to or above the **WLAN** icon in the **VAIO Smart Network** window.

! Turning off the wireless LAN function while accessing remote documents, files, or resources may result in data loss.

Downloaded from LpManual.com Manuals

Using the Bluetooth Function

The Bluetooth® function may be available on your computer.

Features and options in this section may not be available on your computer.
See the specifications to find out about the configuration of your computer.

You can establish wireless communications between your computer and other Bluetooth devices such as another computer or a mobile phone. You can transfer data between these devices without cables at a range of up to 10 meters in an open area.

Notes on using the Bluetooth function

- The data transfer rate varies, depending on the following conditions:
  - Obstacles, such as walls, located between devices
  - Distance between devices
  - Material used in walls
  - Proximity to microwaves and cordless telephones
  - Radio frequency interference and other environmental conditions
  - Device configuration
  - Type of software application
  - Type of operating system
  - Use of both wireless LAN and Bluetooth functions at the same time on your computer
  - Size of file being exchanged
- Large files may occasionally be corrupted during continuous transfer due to limitations of the Bluetooth standard and electromagnetic interference in the environment.

Downloaded from LpManual.com Manuals

- All Bluetooth devices must be certified to make sure that the applicable standard requirements are maintained. Even if standards are met, individual device performance, specifications, and operation procedures can vary. Data exchange may not be possible in all situations.
- Video and audio may not be synchronized if you play videos on your computer with audio output from a connected Bluetooth device. This is a frequent occurrence with Bluetooth technology and is not a malfunction.
- The 2.4 GHz band, with which Bluetooth devices or wireless LAN devices work, is used by various devices. Bluetooth devices use the technology to minimize the interference from other devices that use the same wave length. Simultaneous use of the Bluetooth function and wireless communication devices, however, may cause radio interference and result in reduced communication speeds and distances than the standard values.

  ✍
  Read the Bluetooth regulations guide before using the Bluetooth function.
- The Bluetooth function may not work with other devices, depending on the manufacturer or the software version employed by the manufacturer.
- Connecting multiple Bluetooth devices to your computer may cause channel congestion, resulting in poor performance of the devices. This is normal with Bluetooth technology and is not a malfunction.

Downloaded from LpManual.com Manuals

Bluetooth Security

The Bluetooth wireless technology has an authentication function, which allows you to determine with whom you choose to communicate. With the authentication function, you can prevent any anonymous Bluetooth devices from accessing your computer.

The first time two Bluetooth devices communicate, a common passkey (a password required for authentication) should be determined for both devices to be registered. Once a device is registered, there is no need to re-enter the passkey.

The passkey can be different each time, but must be the same at both ends.

For certain devices, such as a mouse, no passkey can be entered.

Downloaded from LpManual.com Manuals

Communicating with Another Bluetooth Device

You can connect your computer to a Bluetooth device such as another computer, a mobile phone, a PDA, a headset, a mouse, or a digital camera without the use of any cables.

To communicate with another Bluetooth device

To communicate with another Bluetooth device, you first need to set up the Bluetooth function. For setting up and using the Bluetooth function, search for Bluetooth information using **Windows Help and Support**.

1 Turn on the **WIRELESS** switch.

2 Click the button next to or above the **Bluetooth** icon in the **VAIO Smart Network** window. Make sure the **WIRELESS** indicator light turns on.

Downloaded from LpManual.com Manuals

Stopping Bluetooth Communications

To stop Bluetooth communications

1 Turn off the Bluetooth device that is communicating with your computer.

2 Click the button next to or above the **Bluetooth** icon in the **VAIO Smart Network** window.

Downloaded from LpManual.com Manuals

Using Fingerprint Authentication

Your computer may be equipped with a fingerprint sensor to provide you with additional convenience.

Features and options in this section may not be available on your computer.
See the specifications to find out about the configuration of your computer.

Once you have registered your fingerprint(s), the fingerprint authentication function offers:

- A substitute for password entry
  - Logging onto Windows (page 77)
    If you have registered your fingerprints for your user account, you can substitute fingerprint authentication for password entry when logging onto Windows.
  - **Power-on Security** feature (page 77)
    If you have set the power-on password (page 111) and/or the hard disk password (page 116), you can substitute fingerprint authentication for password entry when starting your computer.
- **Password Bank** for quick web site access (page 78)
  You can substitute fingerprint authentication for entering information (user accounts, passwords, etc.) required to access the password-protected web sites.
- **File Safe** feature to encrypt/decrypt data (page 78)
  With the **File Safe** feature, you can encrypt files and folder to create an encrypted archive. To decrypt or access such encrypted archives, you can use the fingerprint authentication or enter the password you specified for encryption.
- Application launcher function for quick application access (page 78)
  Once you have assigned an application to your finger, you can then swipe the finger across the fingerprint sensor to launch the assigned application.

Downloaded from LpManual.com Manuals

Registering a Fingerprint

To use the fingerprint authentication function, you must register your fingerprint(s) in your computer.

Set the Windows password on your computer before registration. See **Adding the Windows Password** **(page 120)** for the detailed instructions.

To register a fingerprint

Up to 10 fingerprints can be registered for each user and up to 21 fingerprints can be registered for logging onto your system using the **Power-on Security** feature. You can also select the fingerprint you want to use for the **Power-on Security** feature later.

1 Click **Start**, **All Programs, Protector Suite QL**, and **Control Center**.

2 Click **Fingerprints** and **Initialize**.

3 Follow the on-screen instructions.

For detailed information, see the help file.

Downloaded from LpManual.com Manuals

If you have failed to register a fingerprint, follow these steps to try again.

1 Place the top joint of your finger on the fingerprint sensor (1).



2 Swipe your finger perpendicularly across the fingerprint sensor.



Downloaded from LpManual.com Manuals

!
Place your fingertip flat in the center of the fingerprint sensor.

Scan your fingerprint from the top joint of the finger to the fingertip.

Keep your finger in contact with the fingerprint sensor while swiping.

Fingerprint registration may fail if you move your finger too fast or too slow. Let the fingerprint sensor take about one second to scan your fingerprint.

You may not be able to register and/or have your fingerprint(s) recognized if your finger is excessively dry or wet, wrinkled, injured, dirty, etc.

Register more than one fingerprint in case that the fingerprint sensor fails to recognize the fingerprint.

Be sure to clean your fingertip(s) and the fingerprint sensor before swiping in order to keep good recognition performance.

Downloaded from LpManual.com Manuals

Logging Onto Your System

To use the fingerprint authentication function in place of password entry to log onto your system, you need to set the power-on, hard disk, and Windows passwords and configure your computer for fingerprint authentication.

For setting the power-on, hard disk, and Windows passwords, see **Setting the Password (page 110)**.

For detailed information, see the help file included with the **Protector Suite QL**.

Logging onto Windows

If you have registered your fingerprints for your user account, you can substitute fingerprint authentication for Windows password entry. To log onto Windows, swipe the registered finger across the fingerprint sensor when the Windows log-on screen appears.

Power-on Security feature

If you have set the power-on password (page 111) and/or the hard disk password (page 116), you can substitute fingerprint authentication for password entry when starting your computer.

Downloaded from LpManual.com Manuals

Using the Password Bank

Once you have registered your user information (user accounts, passwords, etc.) for web sites in the **Password Bank**, you can substitute fingerprint authentication for entering information required to access the password-protected web sites.

For detailed information, see the help file included with the **Protector Suite QL**.

! You may not be able to use the **Password Bank** feature depending on the web site you access.

Using the File Safe Feature

With the **File Safe** feature, you can create an encrypted archive to include a file and/or folder for protection against unauthorized access. The encrypted archive can be decrypted or unlocked for included file/folder access by swiping your finger across the fingerprint sensor or entering the backup password you specified for encryption.

For detailed information, see the help file included with the **Protector Suite QL**.

Using the Application Launcher

The application launcher feature is available on your computer for launching your preferred application (executable file) that is assigned to one of your fingers with a registered fingerprint. Once you have assigned an application to your finger, you can launch the assigned application simply by swiping the finger across the fingerprint sensor.

For detailed information, see the help file included with the **Protector Suite QL**.

Downloaded from LpManual.com Manuals

Using Fingerprint Authentication with the TPM

With the TPM data encryption feature, using fingerprint authentication can strengthen computer security. For instructions on how to use the TPM, see **Using the TPM** **(page 80)**.

To use fingerprint authentication with the TPM, your computer needs to be equipped with both a fingerprint sensor and the TPM. See the specifications to find out about the configuration of your computer.

For detailed information, see the help file included with the **Protector Suite QL**.

Erasing the Registered Fingerprints

Before disposing of your computer or transferring it to a third person, it is strongly recommended you erase the fingerprint data registered on the fingerprint sensor after erasing the data stored on your built-in storage device.

To erase the registered fingerprints

1. Turn on the computer.
2. Press the **F2** key when the VAIO logo appears.
   The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.
3. Press the ← or → key to select **Security** to display the **Security** tab.
4. Press the ↓ key to select **Clear Fingerprint Data** and press the **Enter** key.
5. At the confirmation prompt, select **Continue** and press the **Enter** key.
   The fingerprint data registered on the fingerprint sensor is erased automatically after your system restarts.

Downloaded from LpManual.com Manuals

Using the TPM

The Trusted Platform Module (TPM) may be embedded in your computer to provide basic security functions. In combination with the TPM, you can encrypt and decrypt your data to strengthen computer security against inappropriate access.

See the specifications to find out about the configuration of your computer.

TPMs are defined by Trusted Computing Group (TCG) and also called security chips.

Important Notice

- Do not encrypt the files containing keys to be used for encryption and the folders that include such files. Encrypting the files in the folders containing basic user keys and others, using the Encrypting File System (EFS) will disable you to launch your TPM software and decrypt the encrypted data in the following cases:
  - The TPM software has been installed.
  - The platform has been initialized.
  - The EFS function has been enabled in user initialization process.

  With the default settings, the files in the folders below cannot be encrypted because they have system attributes. Do not change the system attributes of the files in the folders below.

  The following folders are invisible by default.

  - Folders containing basic user keys and others
    C:\<username>\All Users\Infineon\TPM Software 2.0\BackupData
    C:\<username>\All Users\Infineon\TPM Software 2.0\PlatformKeyData
    C:\<username>\All Users\Infineon\TPM Software 2.0\RestoreData
    (C:\<username>\All Users is a shortcut to C:\ProgramData.)
    C:\<username>\<account>\AppData\Roaming\Infineon\TPM Software 2.0\UserKeyData

Downloaded from LpManual.com Manuals

- Do not encrypt any one of the following archive, backup, or token files. There will be no way to restore them if you carelessly encrypt them.
  Sony assumes no liability for any troubles and damages arising out of your careless encryption of the following files and folders including them.
  - Automatic backup file
    Default file name: SPSystemBackup.xml
    Default path: None (Clicking **Browse** displays the **<userfolder>\Documents\Security Platform** window.)
  - Storage folder for automatic backup data
    Default folder name: SPSystemBackup
    The folder is created as the subfolder for the SPSystemBackup.xml file.
  - Token file for restoring the TPM configuration
    Default file name: SPEmRecToken.xml
    Default path: Removable media (FD, USB memory, etc.)
  - Key and certificate backup file
    Default file name: SpBackupArchive.xml
    Default path: None (Clicking **Browse** displays the **<userfolder>\Documents\Security Platform** window.)
  - PSD backup file
    Default file name: SpPSDBackup.fsb
    Default path: None (Clicking **Browse** displays the **<userfolder>\Documents\Security Platform** window.)

Downloaded from LpManual.com Manuals

- Do not encrypt any one of the following password reset token or secret files. There will be no way to reset the password if you carelessly encrypt them.
  Sony assumes no liability for any troubles and damages arising out of your careless encryption of the following files and folders including them.
  - Password reset token file
    Default file name: SPPwdResetToken.xml
    Default path: Removable media (FD, USB memory, etc.)
  - Password reset secret file
    Default file name: SPPwdResetSecret.xml
    Default path: Removable media (FD, USB memory, etc.)

Downloaded from LpManual.com Manuals

Configuring the TPM

To use the embedded TPM, you need to:

1 Enable the TPM in the BIOS setup screen.

2 Install the **Infineon TPM Professional Package**.

3 Initialize and configure the TPM.

To enable the TPM in the BIOS setup screen

1 Turn on your computer.

2 Press the **F2** key when the VAIO logo appears.
The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.

3 Press the ← or → key to select the **Security** tab, the ↑ or ↓ key to select **Change TPM State**, and then the **Enter** key.

4 Press the ↑ or ↓ key to select **Enable** and then the **Enter** key.

5 Press the ← or → key to select **Exit**, select **Exit Setup**, and then press the **Enter** key.

6 After your system restarts, select **Execute** in the confirmation window and then press the **Enter** key.

✍
You can also disable the TPM and clear the TPM configuration in the BIOS setup screen.

!
Before enabling the TPM, be sure to set the power-on and hard disk passwords to protect against unauthorized modification of the TPM configuration.

If the TPM is enabled, it will take longer before the VAIO logo appears due to security checks at computer startup.

You will not be able to access any TPM-protected data if you clear the TPM ownership. Before clearing the TPM configuration, be sure to make backup copies of the TPM-protected data.

Downloaded from LpManual.com Manuals

To install the Infineon TPM Professional Package

Read the Readme.txt in the **C:\Infineon\Readme** folder. Then, double-click **setup.exe** in the **C:\Infineon** folder to install the package.

To install this package, you must have administrative rights on the computer.

!
You need to set a few passwords while installing the **Infineon TPM Professional Package**. Without these passwords, you will not be able to restore any TPM-protected data or backup files. Be sure to write down the passwords and keep them safe and private from other people.

To initialize and configure the TPM

See the on-screen documentation for detailed information. To open the documentation, click **Start**, **All Programs**, **Infineon Security Platform Solution**, and **Help**.

!
The maintenance and management of TPM-protected data must be carried out at your own risk. Sony assumes no liability for any defects arising out of your data maintenance and management.

Downloaded from LpManual.com Manuals

Using Peripheral Devices

You can add functionality to your VAIO computer by using the various ports on the computer.

❑ **Connecting a Docking Station (page 86)**
❑ **Connecting External Speakers or Headphones (page 94)**
❑ **Connecting an External Display (page 95)**
❑ **Selecting Display Modes (page 100)**
❑ **Using the Multiple Monitors Function (page 102)**
❑ **Connecting an External Microphone (page 104)**
❑ **Connecting a USB Device (page 105)**
❑ **Connecting an i.LINK Device (page 107)**

Downloaded from LpManual.com Manuals

Connecting a Docking Station

Attaching a docking station enables you to connect additional peripherals to your computer, such as a printer and an external display.

A docking station is not supplied with your computer and is available as an optional accessory.

Downloaded from LpManual.com Manuals

Locating Ports on the Docking Station



1 **DC IN** indicator
Illuminates when the docking station is powered.
2 **IN USE** indicator (page 91)
3 **UNDOCK** button (page 91)
4 **DC IN** port (page 88)
5 Hi-Speed USB (USB 2.0) ports* (page 105)
6 Network (Ethernet) port (1000BASE-T / 100BASE-TX / 10BASE-T) (page 58)
7 **DVI-D** port (page 96)
8 **MONITOR** port (page 96)
9 Security slot

* Support high-/full-/low- speeds.

!
The docking station can be powered only through the AC adapter supplied with the docking station. Do not unplug the AC adapter from the docking station and the AC outlet while using the docking station. This may cause data damage or hardware malfunctions.

Downloaded from LpManual.com Manuals

Attaching Your Computer to the Docking Station

!
Be sure to install the battery pack before attaching your computer to the docking station.

To attach your computer to the docking station

!
Be sure to use the AC adapter supplied with the docking station.

Do not move your computer while it is attached to the docking station. This may detach the docking station and cause damage to both units.

1 Disconnect all peripherals and the AC adapter from the computer.

2 Plug one end of the power cord (1) into the AC adapter (2) and the other end into an AC outlet.

3 Plug the cable connected to the AC adapter (2) into the **DC IN** port (3) on the docking station (4).



Downloaded from LpManual.com Manuals

4 Slide open the docking station connector cover on the bottom of the computer.



5 Align the rear bottom corners of the computer with the guides on the docking station.



Downloaded from LpManual.com Manuals

6 Gently push down the computer until it clicks into place.



7 Turn on the computer.

Downloaded from LpManual.com Manuals

Disconnecting Your Computer from the Docking Station

!
Make sure that no devices connected to the docking station are in use before disconnecting your computer.

Do not disconnect your computer from the docking station while the **IN USE** indicator light is lit. Disconnecting the computer while the **IN USE** indicator is lit may result in loss of unsaved data or a failure of the computer.

When the battery pack is running out of power, disconnecting your computer from the docking station may result in loss of unsaved data.

Do not disconnect your computer from the docking station during video playback. Be sure to close video playback software before disconnection.

Once you have completed the steps in **To disconnect your computer from the docking station** **(page 92)**, be sure to take your computer off the docking station. Use of the computer while on the docking station may cause unstable operations.

Downloaded from LpManual.com Manuals

To disconnect your computer from the docking station

1 Press the **UNDOCK** button (1) and wait until the **IN USE** indicator light (2) turns off.



If the **IN USE** indicator is unlit, you do not have to press the **UNDOCK** button.

Pressing the **UNDOCK** button while your computer is in a power saving mode brings the computer to Normal mode first, and then initiates the disconnection process.

Once you have placed your computer back in Normal mode, be sure to take your computer off the docking station. Use of the computer while on the docking station may cause unstable operations.

Downloaded from LpManual.com Manuals

2 Lift the computer off the docking station.



3 Close the docking station connector cover on the bottom of the computer.

Alternatively, you can disconnect the computer from the docking station as follows:

1 Click **Start**, the arrow next to the **Lock** button, and **Undock**.

2 Make sure that a message balloon appears and the **IN USE** indicator light turns off. Then lift the computer off the docking station.

3 Close the docking station connector cover on the bottom of the computer.

! It is extremely important that you close the docking station connector cover after disconnecting your computer from the docking station. If the cover is left open, dust may get inside and damage the computer.

✍ To disconnect the docking station completely from AC power, unplug the AC adapter.

Downloaded from LpManual.com Manuals

Connecting External Speakers or Headphones

You can connect external sound output devices (not supplied), such as speakers or headphones, to your computer.

Since your computer is capable of outputting digital signals through the **OPTICAL OUT** port, you can connect an S/PDIF device such as digital headphones or an audio/video amplifier to the port and enhance the sound quality of your computer. For more information, see the manual that came with your S/PDIF device.

!
To hear sound from the S/PDIF device connected to the **OPTICAL OUT** port, you need to change the sound output device. For the detailed instructions, see **How do I change the sound output device?** **(page 200)**.

To connect external speakers

✍
Make sure your speakers are designed for computer use.

!
Turn down the volume of the speakers before you turn them on.

Connect external speakers (1) to the headphones jack (2) ∩ with a speaker cable (3) (not supplied).



Downloaded from LpManual.com Manuals

Connecting an External Display

You can connect an external display (not supplied) to your computer. For example, you can use the computer with a computer display or a projector.

Connect the power cord of your external display after connecting all other cables.

Features and options in this section may not be available on your computer.

Downloaded from LpManual.com Manuals

Connecting a Computer Display

You can connect a computer display (monitor) either directly to your computer or via the optional docking station.

To connect a computer display

! The monitor port on your computer is not accessible when the computer is attached to the docking station.

1. If necessary, plug one end of the display's power cord (1) into your display, and the other end into an AC outlet.
2. If you want to connect an analog monitor, plug the display cable (2) into the monitor port (3) on the computer or on the docking station.
3. If you want to connect a TFT/DVI monitor, plug the display cable into the **DVI-D** port on the docking station.



DVI-D stands for Digital Visual Interface - Digital. It is a type of DVI port that supports only digital video signals (no analog video signals). It has 24 pins.

A DVI-I (Digital Visual Interface - Integrated) port supports digital video and analog video signals. It has 29 pins.

Downloaded from LpManual.com Manuals

Connecting a Multimedia Computer Display

You can connect a multimedia computer display that includes built-in speakers and a microphone either directly to your computer or via the optional docking station.

Downloaded from LpManual.com Manuals

To connect a multimedia computer display

!
The monitor port on your computer is not accessible when the computer is attached to the docking station.

1 Plug the power cord of your multimedia computer display (1) into an AC outlet.

2 Plug the display cable (2) into the monitor port (3) on the computer or on the docking station.

3 Plug the speaker cable (4) into the headphones jack (5) on the computer.

4 Plug the microphone cable (6) into the microphone jack (7) on the computer.



Downloaded from LpManual.com Manuals

Connecting a Projector

You can connect a projector (for example, the Sony LCD projector) either directly to your computer or via the optional docking station.

To connect a projector

! The monitor port on your computer is not accessible when the computer is attached to the docking station.

1. Connect the power cord (1) of your projector into an AC outlet.
2. Plug a display cable (2) into the monitor port (3) on the computer or on the docking station.
3. Plug an audio cable (4) into the headphones jack (5) on the computer.
4. Plug the display cable and the audio cable into the port and jack on the projector (6).



Downloaded from LpManual.com Manuals

Selecting Display Modes

When an external display is connected, you can select either your computer screen or the connected display to use as the primary monitor.

If you want to work on your computer screen and the external display at the same time, see **Using the Multiple Monitors Function** **(page 102)** for more information.

The procedure for selecting a display depends on the video controller used in the computer.
See the specifications to find out about the configuration of your computer.

Downloaded from LpManual.com Manuals

To select a display

You may not be able to display the same contents on your computer screen and the external display or projector at the same time, depending on the type of your external display or projector.

Turn on the external display before turning on your computer.

- On models with the Intel Graphics Media Accelerator
  1. Right-click on the desktop and select **Personalize**.
  2. Click **Display Settings**.
  3. Follow the on-screen instructions to change the settings.
- On models with the NVIDIA video controller
  1. Click **Start** and **Control Panel**.
  2. Click **Additional Options**.
  3. Click **NVIDIA Control Panel**.
  4. Select the display setup option under **Display**.
  5. Follow the on-screen instructions to change the settings.
- On models with the ATI video controller

  When the computer has an external display connected, you can change the Main/Clone setting as follows:
  1. Click **Start**, **All Programs**, and **Catalyst Control Center**.
  2. Click **CCC**.
  3. Follow the on-screen instructions to change the settings.
     See the help file for more information.

Downloaded from LpManual.com Manuals

Using the Multiple Monitors Function

The Multiple Monitors function allows you to distribute portions of your desktop across separate displays. For example, if you have an external display connected to the monitor port, your computer screen and the external display can function as a single desktop.

The procedure for using the Multiple Monitors function depends on the video controller used in the computer. See the specifications to find out about the configuration of your computer.

You can move the cursor from one display to the other. This allows you to drag objects, such as an open application window or a toolbar, from one display to the other.



Downloaded from LpManual.com Manuals

To use the Multiple Monitors function

✍
Your external display may not support the Multiple Monitors function.

Certain software applications may not be compatible with Multiple Monitors settings.

Make sure that your computer does not enter Sleep or Hibernate mode while you are using the Multiple Monitors function. Otherwise, the computer may not return to Normal mode.

If you set different colors on each display, do not expand a single window across two displays. Otherwise, your software may not work properly.

Set fewer colors or a lower resolution for each display.

❑ On models with the Intel Graphics Media Accelerator

1. Right-click on the desktop and select **Personalize**.
2. Click **Display Settings**.
3. Follow the on-screen instructions to change the settings.

❑ On models with the NVIDIA or ATI video controller

1. Click **Start** and **Control Panel**.
2. Click **Adjust screen resolution** under **Appearance and Personalization**.
3. Right-click the number **2** monitor and select **Attached**.
4. Click **OK**.
   At the confirmation prompt, click **Yes**.

✍
You can also change the **S1** button assignment to activate the Multiple Monitors function with the **S1** button. To change the **S1** button assignment, press and hold the **S1** button to display the window for changing the assignment.

Downloaded from LpManual.com Manuals

Connecting an External Microphone

If you use a sound input device (for example, to chat over the Internet), you need to connect an external microphone (not supplied).

To connect an external microphone

Plug the microphone cable (1) into the microphone jack (2) .



Make sure your microphone is designed for computer use.

Downloaded from LpManual.com Manuals

Connecting a USB Device

You can connect a Universal Serial Bus (USB) device to your computer, such as a mouse, floppy disk drive, speaker, and printer.

!
You cannot use USB devices if you disable the USB ports in the BIOS setup screen. To enable the ports, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

If the use of USB ports is restricted by the **USB Access Restriction Setting** utility, you cannot use USB devices. To change the setting, see **Restricting USB Access** **(page 132)**.

To connect a USB device

1 Choose the USB port (1) you prefer to use.

2 Plug the USB device cable (2) into the USB port.



Downloaded from LpManual.com Manuals

Notes on connecting a USB device

- You may need to install the driver software supplied with your USB device before use. See the manual that came with the USB device for more information.
- Be sure to use a USB printer compatible with your version of Windows to print documents.
- For information on how to remove a USB device, see the manual that came with the device.
- To protect your computer and/or USB devices from damage, observe the following:
  - When moving the computer with USB devices connected, avoid exposing the USB ports to shock or impact.
  - Do not put the computer into a bag or carrying case when it has USB devices connected.

Downloaded from LpManual.com Manuals

Connecting an i.LINK Device

Your computer is equipped with an i.LINK port which you can use to connect an i.LINK device, such as a digital video camcorder.

i.LINK is a trademark of Sony Corporation used only to designate that a product contains an IEEE 1394 connection. The procedure to establish an i.LINK connection may vary, depending on a software application, an operating system, and a compatible i.LINK device. Not all products with an i.LINK connection can communicate with each other. See the manual that came with your compatible i.LINK device for more information on operating conditions and proper connection. Before connecting compatible i.LINK PC peripherals to your system, such as a CD-RW or hard disk drive, confirm their operating system compatibility and required operating conditions.

Notes on connecting i.LINK devices

- The i.LINK port on your computer does not supply power to an external device. If the external device requires external power, be sure to connect it to a power source.
- The i.LINK port supports transfer rates up to 400 Mbps. However, the actual transfer rate depends on the transfer rate of the external device.
- The optional i.LINK cables may not be available in some countries or areas.
- An i.LINK connection with other compatible devices is not fully guaranteed.
- The i.LINK connection may not be available depending on the software applications, operating system, and i.LINK-compatible devices you use. See the manual that came with your software for more information.
- Check the working conditions and operating system compatibility of i.LINK-compatible PC peripherals (for example, an HDD or a CD-RW drive) before you connect them to your computer.
- You cannot use i.LINK devices if you disable the i.LINK port in the BIOS setup screen. To enable the port, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

Downloaded from LpManual.com Manuals

Connecting a Digital Video Camcorder

To connect a digital video camcorder

Plug one end of an i.LINK cable (1) (not supplied) into the i.LINK port (2) on the computer and the other end into the DV In/ Out port (3) on the digital video camcorder.



The connection procedure varies depending on your compatible i.LINK device. See the manual that came with the device for more information.

You cannot access the pictures stored on a Memory Stick when using an i.LINK connection.

Downloaded from LpManual.com Manuals

Customizing Your VAIO Computer

This section briefly describes how to change the main settings of your VAIO computer. Among other things, you will learn how to use and customize the look of your Sony software and utilities.

❑ **Setting the Password (page 110)**
❑ **Using the VAIO Control Center (page 122)**
❑ **Using the Power Saving Modes (page 123)**
❑ **Using the VAIO Power Management (page 128)**
❑ **Protecting Data from Unauthorized Use (page 130)**
❑ **Protecting the Hard Disk (page 133)**
❑ **Configuring Your Modem (page 134)**

Downloaded from LpManual.com Manuals

Setting the Password

In addition to the Windows password, you can use BIOS functions to set two types of passwords to protect your computer: the power-on password and the hard disk password.

Once you have set the power-on password, you will be prompted to enter the password after the VAIO logo appears to start your computer. The power-on password allows you to protect your computer from unauthorized access.

The hard disk password provides additional security for the data stored on your built-in storage device. If you set the hard disk password, other users will not be able to access the data without knowing the password, even if the password-protected built-in storage device is removed from your computer and is installed in another computer.

Downloaded from LpManual.com Manuals

Adding the Power-on Password

The power-on password is provided to protect your computer from unauthorized access.

There are two types of the power-on passwords: the machine password and the user password. The machine password is provided for users with administrative rights on the computer to change all the setup options in the BIOS setup screen, as well as to start the computer. The user password is provided for the standard users to allow for changing some of the BIOS setup options, as well as starting the computer. To set the user password, you must first set the machine password.

!
Once you have set the power-on password, you cannot start your computer without entering the password. Be sure not to forget the password. Write down your password and keep it safe and private from other people.

If you forget the power-on password and need assistance to reset it, a password reset fee will be charged, and your computer may need to be sent in for service to reset the password.

✍
If you have set the power-on password in conjunction with the fingerprint authentication function, you can substitute fingerprint authentication for password entry when turning on your computer. For more information, see **Using Fingerprint Authentication** **(page 73)**.

Downloaded from LpManual.com Manuals

To add the power-on password (machine password)

1. Turn on the computer.
2. Press the **F2** key when the VAIO logo appears.
   The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.
3. Press the ← or → key to select **Security** to display the **Security** tab, select **Set Machine Password**, and then press the **Enter** key.
4. On the password entry screen, enter the password twice and press the **Enter** key.
   The password can be up to 32 alphanumeric characters (including spaces) long.
5. Select **Password when Power On** under **Security** and press the **Enter** key.
6. Change the setting from **Disabled** to **Enabled**.
7. Press the ← or → key to select **Exit**, select **Exit Setup**, and then press the **Enter** key.
   At the confirmation prompt, press the **Enter** key.

Downloaded from LpManual.com Manuals

To add the power-on password (user password)

!
Make sure you set the machine password before setting the user password.

1. Turn on the computer.
2. Press the **F2** key when the VAIO logo appears.
   The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.
3. Enter the machine password and press the **Enter** key.
4. Press the ← or → key to select **Security** to display the **Security** tab, select **Set User Password**, and then press the **Enter** key.
5. On the password entry screen, enter the password twice and press the **Enter** key.
   The password can be up to 32 alphanumeric characters (including spaces) long.
6. Press the ← or → key to select **Exit**, select **Exit Setup**, and then press the **Enter** key.
   At the confirmation prompt, press the **Enter** key.

Downloaded from LpManual.com Manuals

Changing/Removing the Power-on Password

To change or remove the power-on password (machine password)

1. Turn on the computer.
2. Press the **F2** key when the VAIO logo appears.
   The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.
3. Enter the machine password and press the **Enter** key.
4. Press the ← or → key to select **Security** to display the **Security** tab, select **Set Machine Password**, and then press the **Enter** key.
5. On the password entry screen, enter the current password once and a new password twice, and then press the **Enter** key.
   To remove the password, leave the **Enter New Password** and **Confirm New Password** fields blank and press the **Enter** key.
6. Press the ← or → key to select **Exit**, select **Exit Setup**, and then press the **Enter** key.
   At the confirmation prompt, press the **Enter** key.

Downloaded from LpManual.com Manuals

To change or remove the power-on password (user password)

1. Turn on the computer.
2. Press the **F2** key when the VAIO logo appears.
   The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.
3. Enter the user password and press the **Enter** key.
4. Press the ← or → key to select **Security** to display the **Security** tab, select **Set User Password**, and then press the **Enter** key.
5. On the password entry screen, enter the current password once and a new password twice, and then press the **Enter** key.
   To remove the password, leave the **Enter New Password** and **Confirm New Password** fields blank and press the **Enter** key.
6. Press the ← or → key to select **Exit**, select **Exit Setup**, and then press the **Enter** key.
   At the confirmation prompt, press the **Enter** key.

Downloaded from LpManual.com Manuals

Adding the Hard Disk Password

The hard disk password provides additional security for the data stored on your built-in storage device. If you enable the hard disk password, this adds an extra level of security.

When adding the hard disk password, you must set both the master and user passwords. The master password is provided for users with administrative rights on the computer to reset the user password in the BIOS setup screen. The user password is provided to lock your built-in storage device. Once you set the user password, you will have to enter the password along with the power-on password (if set), after the VAIO logo appears.

! You cannot start your computer with the master password.

If you forget the master password or the keyboard fails, which is critical to password entry, no bypass is possible and the data stored on the built-in storage device will not be accessible. There is NO RESET of this password. You will have to replace the built-in storage device at your own expense and lose all the data originally stored on the device. Be sure to write down the master password and keep it safe and private from other people.

✍ If you have set the hard disk password in conjunction with the fingerprint authentication function, you can substitute fingerprint authentication for password entry when turning on your computer. For more information, see **Using Fingerprint Authentication** **(page 73)**.

Downloaded from LpManual.com Manuals

To add the hard disk password

1 Turn on the computer.

2 Press the **F2** key when the VAIO logo appears.
The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.

✍
If you have set the power-on password, enter your power-on password.

3 Press the ← or → key to select **Security** to display the **Security** tab, select **Hard Disk Password**, and then press the **Enter** key.
The **Hard Disk Password** entry screen appears.

4 Select **Enter Master and User Passwords** and press the **Enter** key.

5 Select **Continue** on the warning screen and press the **Enter** key.

6 Enter the master password twice and press the **Enter** key.
The password should be up to 32 alphanumeric characters (including spaces) long.

7 Enter the user password twice and press the **Enter** key.
The password should be up to 32 alphanumeric characters (including spaces) long.

8 At the confirmation prompt, press the **Enter** key.

9 Press the **Esc** key and then the ← or → key to select the **Exit** tab.

10 Press the ↑ or ↓ key to select **Exit Setup** and press the **Enter** key.
At the confirmation prompt, press the **Enter** key.

Downloaded from LpManual.com Manuals

Changing/Removing the Hard Disk Password

To change the hard disk password

1 Turn on the computer.

2 Press the **F2** key when the VAIO logo appears.
The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.

✍
If you have set the power-on password, enter your power-on password.

3 Press the ← or → key to select **Security** to display the **Security** tab, select **Hard Disk Password**, and then press the **Enter** key.
The **Hard Disk Password** entry screen appears.

4 Select **Change Master Password** or **Change User Password** and press the **Enter** key.

5 Enter the current password once and then a new password twice.

6 Press the **Enter** key.

7 Press the **Enter** key when the success message appears.

8 Press the **Esc** key and then the ← or → key to select the **Exit** tab.

9 Press the ↑ or ↓ key to select **Exit Setup** and press the **Enter** key.
At the confirmation prompt, press the **Enter** key.

Downloaded from LpManual.com Manuals

To remove the hard disk password

1. Turn on the computer.
2. Press the **F2** key when the VAIO logo appears.
   The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.

   ✍
   If you have set the power-on password, enter your power-on password.
3. Press the ← or → key to select **Security** to display the **Security** tab, select **Hard Disk Password**, and then press the **Enter** key.
   The **Hard Disk Password** entry screen appears.
4. Select **Enter Master and User Passwords** and press the **Enter** key.
5. Enter the current password for **Enter Current Hard Disk Master Password** and press the **Enter** key.
6. Press the **Enter** key without entering any letter for the remaining fields.
7. Press the **Enter** key when the success message appears.
8. Press the **Esc** key and then the ← or → key to select the **Exit** tab.
9. Press the ↑ or ↓ key to select **Exit Setup** and press the **Enter** key.
   At the confirmation prompt, press the **Enter** key.

Downloaded from LpManual.com Manuals

Adding the Windows Password

The Windows password comes in handy when you have to share a single computer with other people. By setting the Windows password, you can protect your user account from unauthorized access.

Entry of the Windows password will be prompted after you select your user account.

!
Be sure not to forget the password. Write down your password and keep it safe and private from other people.

✍
If your computer is equipped with a fingerprint sensor and you have set the Windows password in conjunction with the fingerprint authentication function, you can substitute fingerprint authentication for password entry when turning on your computer. For more information, see **Using Fingerprint Authentication** **(page 73)**.

To add the Windows password

1. Click **Start** and **Control Panel**.
2. Click **User Accounts and Family Safety** or **User Accounts**.
3. Click **User Accounts**.
4. Click **Create a password for your account** under **Make changes to your account**.
5. In the **New password** and **Confirm new password** fields, enter the password for your account.
6. Click **Create password**.

✍
See **Windows Help and Support** for more information on the Windows password.

Downloaded from LpManual.com Manuals

Changing/Removing the Windows Password

To change the Windows password

1 Click **Start** and **Control Panel**.
2 Click **User Accounts and Family Safety** or **User Accounts**.
3 Click **User Accounts**.
4 Click **Change your password**.
5 In the **Current password** field, enter your current password.
6 In the **New password** and **Confirm new password** fields, enter a new password.
7 Click **Change password**.

To remove the Windows password

1 Click **Start** and **Control Panel**.
2 Click **User Accounts and Family Safety** or **User Accounts**.
3 Click **User Accounts**.
4 Click **Remove your password**.
5 In the **Current password** field, enter the current password that you want to remove.
6 Click **Remove password**.

Downloaded from LpManual.com Manuals

Using the VAIO Control Center

The **VAIO Control Center** utility allows you to access system information and to specify preferences for system behavior.

To use the VAIO Control Center

1. Click **Start**, **All Programs**, and **VAIO Control Center**.
2. Select the desired control item and change the settings.
3. Once finished, click **OK**.
   The setting of the desired item has been changed.

   ✍
   For more information about each option, see the help file included with the **VAIO Control Center**.

   Some of the control items will not be visible if you open the **VAIO Control Center** as a standard user.

Using the VAIO Status Monitor

The **VAIO Status Monitor** utility allows you to check various settings, such as the power management settings, security settings, and current usage of devices, in the **VAIO Status Monitor** window.

To display the VAIO Status Monitor window

1. Click **Start**, **All Programs**, and **VAIO Control Center**.
2. Click **System Information** and **VAIO Status Monitor**.
3. Click **Advanced** in the right pane.

   ✍
   You can change the settings for certain items in the **VAIO Status Monitor** window. To change the settings, select the desired item and click **Settings**.

Downloaded from LpManual.com Manuals

Using the Power Saving Modes

You can take advantage of the power management settings to conserve battery life. In addition to the normal operating mode, your computer has two distinct power saving modes: Sleep and Hibernate. When using battery power, you should be aware that the computer will automatically enter Hibernate mode if the remaining battery life becomes short, regardless of the power management setting you select.

! If the battery charge level falls below 10%, you should either connect the AC adapter to recharge the battery pack or shut down your computer and install a fully charged battery pack.

Using Normal Mode

This is the normal state of the computer when it is in use. The green power indicator light is lit in this mode.

Downloaded from LpManual.com Manuals

Using Sleep Mode

Sleep mode turns off the LCD screen and places the built-in storage device(s) and the CPU into a low power consumption mode. The orange power indicator light blinks slowly in this mode.

!
If you do not intend to use your computer for a long period of time while it is disconnected from AC power, place the computer into Hibernate mode or turn it off.

To activate Sleep mode

Click **Start**, the arrow next to the **Lock** button, and **Sleep**.

✍
When your computer is in Sleep mode, you cannot insert a disc.

Your computer comes out of Sleep mode quicker than out of Hibernate mode.

Sleep mode uses more power than Hibernate mode.

!
If the battery runs out of power while your computer is in Sleep mode, you will lose all unsaved data. Going back to the previous work state is impossible. To avoid loss of data, you should save your data frequently.

To return to Normal mode

- Press any key.
- Press the power button on your computer.

!
If you press and hold the power button for more than four seconds, your computer will turn off automatically. You will lose all unsaved data.

Downloaded from LpManual.com Manuals

If the computer is not used for a certain period of time, it will enter Sleep mode. To modify this, you can change the Sleep mode settings.

To change the Sleep mode settings

1. Right-click the power status icon on the taskbar and select **Power Options**.
2. Click **Change plan settings** under the current power plan.
3. Change the time to place the computer into Sleep mode and click **Save Changes**.

Downloaded from LpManual.com Manuals

Using Hibernate Mode

In Hibernate mode, the state of the system is saved on the built-in storage device(s) and power is turned off. Even when the battery runs out of power, no data will be lost. The power indicator light is unlit in this mode.

✍
If you do not intend to use your computer for a long period of time, place the computer into Hibernate mode.

To activate Hibernate mode

Press the **Fn**+**F12** keys.

The computer enters Hibernate mode.

Alternatively, you can click **Start**, the arrow next to the **Lock** button, and **Hibernate** to place the computer into Hibernate mode.

✍
When your computer is in Hibernate mode, you cannot insert a disc.

Hibernate mode requires more time than Sleep mode to be activated.

Hibernate mode uses less power than Sleep mode.

!
Do not move your computer before its power indicator light turns off.

Downloaded from LpManual.com Manuals

To return to Normal mode

Press the power button.

The computer returns to its normal state.

!
If you press and hold the power button for more than four seconds, your computer will turn off automatically.

✍
It takes more time to return to Normal mode from Hibernate mode than from Sleep mode.

Downloaded from LpManual.com Manuals

Using the VAIO Power Management

Power management helps you set up power schemes for running on AC or battery power to suit your requirements for power consumption.

The **VAIO Power Management** is a software application developed exclusively for VAIO computers. With this software application, you can enhance the Windows power management functions to ensure better operation of your computer and longer battery life. See the help file included with the software for more information.

Selecting a Power Plan

When you start the computer, a power status icon appears on the taskbar. This icon indicates what kind of power source you are using at that time, for example, AC power. Click this icon to display the window that shows your power status.

The **VAIO Power Management** function is added to the Windows **Power Options**.

To select a power plan

1 Right-click the power status icon on the taskbar and select **Power Options**.

2 Select your desired power plan.

To change the power plan settings

1 Click **Change plan settings** under your desired power plan in the **Power Options** window.
Change the Sleep mode and display settings as needed.

2 If you need to change the advanced settings, click **Change advanced power settings** and go to step 3.
Otherwise, click **Save changes**.

3 Click the **VAIO Power Management** tab.
Change the settings for each item.

4 Click **OK**.

Downloaded from LpManual.com Manuals

VAIO Power Management Viewer

To start the VAIO Power Management Viewer

Click on the **VAIO Power Management** tab.

Alternatively, you can use the **VAIO Control Center** to start the **VAIO Power Management Viewer**. Click **Start**, **All Programs**, and **VAIO Control Center**. Double-click **Power Management** in the **VAIO Control Center** window, and then double-click **VAIO Power Management Viewer**.

To change the power scheme

Select the desired power scheme from the drop-down list on the **VAIO Power Management Viewer**.

To view performance with the power scheme modified with the VAIO Power Management

When both the **VAIO Power Management** and the **VAIO Power Management Viewer** are running, the **VAIO Power Management Viewer** shows performance with the power scheme that was modified with the **VAIO Power Management**.

Use the **VAIO Power Management** to set up or modify the power scheme.

Downloaded from LpManual.com Manuals

Protecting Data from Unauthorized Use

Disabling Built-in Devices

You can use one of the BIOS functions to disable the following built-in devices and prohibit external connections and communications.

- **USB Ports**
- **PC Card Slot**
- **Memory Stick Slot**
- **SD Card Slot**
- **i.LINK Port**
- **Optical Disc Drive**
- **Wireless LAN Device**
- **LAN Device** (Ethernet port)

Downloaded from LpManual.com Manuals

To disable built-in devices

1. Turn on the computer.
2. Press the **F2** key when the VAIO logo appears.
   The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.
3. Press the ← or → key to select **Advanced**.
4. Press the ↑ or ↓ key to select your desired built-in device, and press the **Enter** key.
5. Press the ↑ or ↓ key to select **Disabled** and press the **Enter** key.

   ✍
   To enable the device, select **Enabled** instead of **Disabled**.
6. If you want to disable more built-in devices, repeat steps 4 and 5 for each device.
7. Press the ← or → key to select **Exit**, select **Exit Setup**, and then press the **Enter** key.
   At the confirmation prompt, press the **Enter** key.

Downloaded from LpManual.com Manuals

Restricting USB Access

Your computer has the **USB Access Restriction Setting** utility installed for protecting your data from unauthorized use. With this software, you can put restrictions on the use of USB ports.
To start this software, you need to log onto your computer as a user with administrative rights.

To use the USB Access Restriction Setting utility

1. Click **Start**, **All Programs**, and **VAIO Control Center**.
2. Click **Security** and **USB Access Restriction Setting**.
   The password authentication window appears.

   The first time you use the **USB Access Restriction Setting** utility, you need to set the password for authentication.
3. Enter the password and click **OK**.
4. Select an option as desired.
5. Click **OK**.
6. Click **Yes** when a message prompting you to restart your computer appears.
   You need to restart the computer to put the new setting into effect.

Downloaded from LpManual.com Manuals

Protecting the Hard Disk

Your computer has the **VAIO HDD Protection** utility preinstalled for customizing your settings for protecting your hard disk drive against shock hazards. You can select the sensitivity level of the built-in shock sensor to set the appropriate protection level.

Activating VAIO HDD Protection

To protect your hard disk drive against shock hazards, you must first activate the **VAIO HDD Protection**.

To activate VAIO HDD Protection

1. Click **Start**, **All Programs**, and **VAIO Control Center**.
2. Click **Security** and **Hard Disk Drive Protection Settings**.
3. Select the **Activate hard disk drive protection** check box.
4. Select one of the desired sensitivity level.
5. Click **OK**.
   For more information, see the help file included with the software.

! The **VAIO HDD Protection** is designed to minimize possibilities of damage to hard disk drives and user data. It does not ensure 100% data protection under any circumstances.

Hard disk drive protection is disabled before Windows launches, and during a shift to Hibernate or Sleep mode, system recovery, and system shutdown.

Downloaded from LpManual.com Manuals

Configuring Your Modem

Before you can start using your internal modem (not all modems are built-in), or each time you use your modem while traveling, make sure that the country of the active location defined in the **Phone and Modem Options** window matches the country you are dialing from.

To change the country settings for your modem

1. Click **Start** and **Control Panel**.
2. Click **Hardware and Sound**.
3. Click **Phone and Modem Options**.
   The **Location Information** window appears.
4. Enter the required information, and then click **OK**.
   The **Phone and Modem Options** window appears.
5. Select your location on the **Dialing Rules** tab.
6. Click the **Edit** button to change the current configuration.
   The **Edit Location** window appears.
   Or
   Click the **New** button to configure your modem.
   The **New Location** window appears.
7. Check the country/region settings, and make sure it matches the place you are dialing from.

   ✍
   Pulse dial may not be supported in some counties or areas.
8. If you modified your location settings, click **Apply**, and then **OK**.
   The **Phone and Modem Options** window appears.

Downloaded from LpManual.com Manuals

9 Check that your modem is listed on the **Modems** tab.
If your modem is not listed, click **Add** and follow the wizard.

10 Click **Apply/OK**. Your modem is configured.

!
Before applying new country settings, make sure your phone cable is disconnected from your computer.

Downloaded from LpManual.com Manuals

Upgrading Your VAIO Computer

Your VAIO computer and memory modules use high precision components and electronic connectors technology. To avoid invalidation of the warranty during your product warranty period, we recommend that:

- You should contact your dealer to install a new memory module.
- You should not install it yourself, if you are not familiar with upgrading memory on a computer.
- You should not touch the connectors or open the memory module compartment cover.

Contact VAIO-Link if you need assistance.

The type of module and the amount of memory installed on your computer may differ depending on the model you purchased. See the specifications to find out about the configuration of your computer.

Downloaded from LpManual.com Manuals

Adding and Removing Memory

If you want to expand the functionality of your computer, you can increase the amount of memory by installing optional memory modules. Before you upgrade your computer's memory, read the notes and procedures in the following pages.

Notes on adding/removing memory modules

- Be sure to place your computer on a flat surface before adding or removing memory modules.
- Be careful when changing memory. Improper installation of memory modules may cause damage to your system. This damage may void your manufacturer's warranty.
- Only use memory modules that are compatible with your computer. If a memory module is not detected by the computer or the Windows operating system becomes unstable, contact the sales dealer or the manufacturer of your memory module.
- Electrostatic discharge (ESD) can damage electronic components. Before touching a memory module, ensure the following:
  - The procedures described in this document assume user familiarity with the general terminology associated with personal computers and with the safety practice and regulatory compliance requirements for using and modifying electronic equipment.
  - Turn off your computer and disconnect it from its power sources (battery pack and AC adapter) and from any telecommunication links, networks, or modems before you remove any cover or panel from the computer. Failure to do so may result in personal injury or equipment damage.
  - ESD can damage memory modules and other components. Install the memory module only at an ESD workstation. If such a station is not available, do not work in a carpeted area, and do not handle materials that produce or hold static electricity (cellophane wrappers, for example). Ground yourself by maintaining contact with an unpainted metal portion of the chassis while performing the procedure.
  - Do not open the memory module package before you are ready to change the module. The package protects the module from ESD.

Downloaded from LpManual.com Manuals

- Use the special bag supplied with the memory module or wrap the module in aluminum foil to protect it from ESD.
- Introducing any liquids, foreign substances, or objects into the memory module slots or other internal components of your computer will result in damage to the computer and any repair costs will not be covered by the warranty.
- Do not place the memory module in a location subject to:
  - Heat sources such as radiators or air ducts
  - Direct sunlight
  - Excessive dust
  - Mechanical vibration or shock
  - Strong magnets or speakers that are not magnetically shielded
  - Ambient temperature of more than 35°C or less than 5°C
  - High humidity
- Handle the memory module with care. To avoid injuries to your hands and fingers, do not touch the edges of the components and circuit boards inside your computer.

Downloaded from LpManual.com Manuals

Removing and Installing a Memory Module

To change or add a memory module

1 Shut down the computer and disconnect all peripheral devices.

2 Unplug the computer and remove the battery pack.

3 Wait about an hour until the computer cools down.

4 Unscrew the screw (indicated by the arrow below) on the bottom of the computer and remove the memory module compartment cover.



5 Touch a metal object to discharge static electricity.

Downloaded from LpManual.com Manuals

6 Remove the currently installed memory module as follows:

- ❑ Pull the latches in the direction of the arrows (1).
  The memory module is released.
- ❑ Make sure that the memory module tilts up and then pull it out in the direction of the arrow (2).



7 Remove the new memory module from its packaging.

Downloaded from LpManual.com Manuals

8 Slide the memory module into the memory module slot and push it in until it clicks into place.



! Do not touch any other components on the motherboard.

If you want to install only one memory module, be sure to use the lower slot.

Be sure to insert the connector edge of the memory module into the slot while aligning the notch on the module with the small projection in the open slot. Do not force the memory module into the slot in a wrong orientation, as it may cause damage to the slot and the module.

9 Replace the memory module compartment cover.

10 Tighten the screw on the bottom of the computer.

11 Reinstall the battery pack and turn on the computer.

Downloaded from LpManual.com Manuals

Viewing the Amount of Memory

To view the amount of memory

1. Turn on the computer.
2. Click **Start**, **All Programs**, and **VAIO Control Center**.
3. Click **System Information** and **System Information**.
   You can view the amount of system memory in the right pane. If the additional memory does not appear, repeat the installation procedure and restart the computer.

Downloaded from LpManual.com Manuals

Precautions

This section describes safety guidelines and precautions to help you protect your VAIO computer from potential damage.

❑ **Handling the LCD Screen (page 144)**
❑ **Using the Power Source (page 145)**
❑ **Handling Your Computer (page 146)**
❑ **Handling the Built-in Camera (page 149)**
❑ **Handling Discs (page 150)**
❑ **Using the Battery Pack (page 151)**
❑ **Using Headphones (page 152)**
❑ **Handling the Memory Stick (page 153)**
❑ **Handling the Built-in Storage Device (page 154)**
❑ **Using Fingerprint Authentication (page 155)**
❑ **Using the TPM (page 156)**

Downloaded from LpManual.com Manuals

Handling the LCD Screen

- Do not leave the LCD screen facing the sun. This could damage the LCD screen. Be careful when using your computer near a window.
- Do not scratch the surface of the LCD screen or exert pressure on it. This could cause a malfunction.
- Using your computer in low temperature conditions may produce a residual image on the LCD screen. This is not a malfunction. When the computer returns to normal temperature, the screen returns to normal.
- A residual image may appear on the LCD screen if the same image is displayed for a long period of time. The residual image disappears after a while. You can use a screen saver to prevent residual images.
- The LCD screen becomes warm during operation. This is normal and does not indicate a malfunction.
- The LCD screen is manufactured using high-precision technology. You may, however, see tiny black points and/or bright points (red, blue, or green) that continuously appear on the LCD screen. This is a normal result of the manufacturing process and does not indicate a malfunction.
- Avoid rubbing the LCD screen. This could damage the screen. Use a soft, dry cloth to wipe the surface of the LCD screen.
- Do not change the LCD screen orientation setting in the **Tablet PC Settings** window even when there are change options available for selection, as this may make your computer unstable. Sony assumes no liability for any malfunctions arising from changes to the settings.
- Do not exert pressure on the LCD screen lid with the lid closed as it may scratch the LCD screen or soil it.

Downloaded from LpManual.com Manuals

Using the Power Source

See the specifications to find out about the configuration of your computer.

- Do not share the AC outlet with other power-consuming equipment, such as a photocopier or a shredder.
- You can purchase a power strip with a surge protector. This device helps prevent damage to your computer caused by sudden power surges, in an electrical storm, for example.
- Do not place heavy objects on the power cord.
- To disconnect the cord, pull it out by holding the plug. Never pull the cord itself.
- Unplug your computer from the AC outlet if you are not planning to use the computer for a long period of time.
- Make sure that the AC outlet is easily accessible.
- When the AC adapter is not used, unplug it from the AC outlet.
- Use the AC adapter supplied with your computer or genuine Sony products. Do not use any other AC adapter as it may cause a malfunction.

Downloaded from LpManual.com Manuals

Handling Your Computer

- Clean the cabinet with a soft cloth, which is dry or lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder, or solvent such as alcohol or benzine, as these may damage the finish of your computer.
- If you drop a solid object or any liquid onto your computer, shut down the computer, unplug it, and remove the battery pack. You may want to have the computer checked by qualified personnel before operating it again.
- Do not drop your computer or place any objects on top of the computer.
- Do not place your computer in a location subject to:
  - Heat sources, such as radiators or air ducts
  - Direct sunlight
  - Excessive dust
  - Moisture or rain
  - Mechanical vibration or shock
  - Strong magnets or speakers that are not magnetically shielded
  - Ambient temperature of more than 35°C or less than 5°C
  - High humidity
- Do not place electronic equipment near your computer. The electromagnetic field of the equipment may cause the computer to malfunction.
- Use your computer on a solid, stable surface.

Downloaded from LpManual.com Manuals

- We advise not to use your computer directly on your lap. The temperature of the bottom of the unit may rise during normal operation, and after an extended period of time, could cause discomfort or burns.
- Provide adequate air circulation to prevent internal overheating. Do not place your computer on porous surfaces such as rugs, blankets, couches, or beds, or near draperies that may block its air vents.
- Your computer uses high-frequency radio signals and may cause interference to radio or TV reception. If this occurs, relocate the computer a suitable distance away from the set.
- Use only specified peripheral equipment and interface cables. Otherwise, problems may occur.
- Do not use cut or damaged connection cables.
- If your computer is brought directly from a cold location to a warm one, moisture may condense inside the computer. In this case, allow at least one hour before turning on the computer. If any problems occur, unplug the computer and contact VAIO-Link.
- Make sure you disconnect the AC adapter and remove the battery pack before cleaning your computer.
- To avoid losing data when your computer is damaged, back up your data regularly.

Downloaded from LpManual.com Manuals

- Do not exert pressure on the LCD screen or its edges when opening the LCD screen lid or lifting your computer. The LCD screen may be sensitive to pressure or added stress, and exerting pressure may damage the screen or cause it to malfunction. To open the computer, hold the base with one hand and gently lift the LCD screen lid with the other. To carry the computer with the lid open, be sure to hold the computer with both hands.



- Use a carrying case specially designed to carry your computer.

Downloaded from LpManual.com Manuals

Handling the Built-in Camera

Features and options in this section may not be available on your computer.
See the specifications to find out about the configuration of your computer.

- Do not touch the lens protection cover of the built-in camera, as it may cause scratches on the cover and such scratches will appear on the captured images.
- Do not let the direct sunlight get into the lens of the built-in camera regardless of your computer's power state, as it may cause the camera to malfunction.
- The built-in camera is disabled while videos or still images are imported from an i.LINK-compatible device connected to the i.LINK port.
- Clean the lens protection cover of the built-in camera with a blower brush or a soft brush. If the cover is extremely dirty, wipe it off with a soft dry cloth. Do not rub the cover, as it is sensitive to pressure.

Downloaded from LpManual.com Manuals

Handling Discs

- Fingerprints and dust on the surface of a disc may cause read errors. Always hold the disc by its edges and central hole, as shown below:



- Proper care of the disc is essential to its continuous reliability. Do not use solvents (such as benzine, thinner, alcohol, commercially available cleaners, or anti-static spray) which may cause damage to the disc.
- For normal cleaning, hold the disc by its edges and use a soft cloth to wipe the surface from the center out.
- If the disc is badly soiled, moisten a soft cloth with water, wring it out well, and use it to wipe the surface of the disc from the center out. Wipe off any remaining moisture with a dry soft cloth.
- Never affix an adhesive label to a disc. This will affect the use of the disc and may result in irreparable damage.

Downloaded from LpManual.com Manuals

Using the Battery Pack

- Do not leave battery packs in temperatures above 60°C, such as in a car parked in the sun or under direct sunlight.
- Battery life is shorter in a cold environment. This is due to decreased battery efficiency at low temperatures.
- Charge battery packs at temperatures between 10°C to 30°C. Lower temperatures require longer charging time.
- Certain rechargeable battery packs do not meet Sony quality and safety standards. For safety reasons this computer only functions with genuine Sony battery packs designed for this model. If an unauthorized battery pack is installed, the battery pack will not be charged and the computer will not function.
- While the battery pack is in use or being charged, heat builds up in the battery pack. This is normal and is not cause for concern.
- Keep the battery pack away from all sources of heat.
- Keep the battery pack dry.
- Do not open or try to disassemble the battery pack.
- Do not expose the battery pack to any mechanical shock, such as dropping it on a hard surface.
- If you are not using your computer for a long period of time, remove the battery pack from the computer to prevent damage to the battery pack.
- If you have not used the battery pack for a considerable amount of time, the remaining battery life may become short. However, this is normal and does not indicate a malfunction, because the battery pack will gradually discharge over time even when not in use. Connect the AC adapter to your computer and recharge the battery pack before using the computer again.
- You do not need to discharge the battery pack before recharging.
- If the battery pack quickly runs out of power after fully charged, it may be reaching the end of its life and should be replaced.

Downloaded from LpManual.com Manuals

Using Headphones

- **Road safety** – Do not use headphones while driving, cycling, or operating any motorized vehicle. It may create a traffic hazard and is illegal in some areas. It can also be potentially dangerous to play loud music while walking, especially at pedestrian crossings.
- **Preventing hearing damage** – Avoid using headphones at high volume. Hearing experts advise against continuous, loud and extended play. If you experience a ringing in your ears, reduce the volume or discontinue use.

Downloaded from LpManual.com Manuals

Handling the Memory Stick

- Do not touch the Memory Stick connector with your finger or metallic objects.
- Use only the adhesive label supplied with the Memory Stick as a label.
- Do not bend, drop, or expose the Memory Stick.
- Do not disassemble or modify the Memory Stick.
- Do not let the Memory Stick get wet.
- Do not use or store the Memory Stick in a location subject to:
  - Static electricity
  - Electrical noise
  - Extremely high temperatures, such as in a car parked in the sun
  - Direct sunlight
  - High humidity
  - Corrosive substances
- Use the storage case supplied with the Memory Stick.
- Be sure to make a backup copy of your valuable data.
- Keep the Memory Stick and the Memory Stick adaptors out of reach of children. There is a risk of swallowing them.
- When using the Memory Stick Duo, do not use a fine-tipped pen to write on the label adhered to the Memory Stick Duo. Exerting pressure on the media may damage internal components.

Downloaded from LpManual.com Manuals

Handling the Built-in Storage Device

The built-in storage device (hard disk drive or solid state drive) has a high storage density and reads or writes data in a short time. However, it can be easily damaged if improperly used. If the built-in storage device is damaged, the data cannot be restored. To prevent losing data, you should be careful when handling your computer.

Features and options in this section may not be available on your computer.
See the specifications to find out about the configuration of your computer.

To avoid damaging your hard disk drive

- Do not subject your computer to sudden movements.
- Keep your computer away from magnets.
- Do not place your computer in a location subject to mechanical vibration or in an unstable position.
- Do not move your computer while the power is on.
- Do not turn off the power or restart your computer while reading or writing data to the hard disk drive.
- Do not use your computer in a place subject to extreme changes in temperature.
- Do not remove the hard disk drive from your computer.

To avoid damaging your solid state drive

- Do not turn off the power or restart your computer while reading or writing data to the solid state drive.
- Do not remove the solid state drive from your computer.

Downloaded from LpManual.com Manuals

Using Fingerprint Authentication

Features and options in this section may not be available on your computer.
See the specifications to find out about the configuration of your computer.

- The fingerprint authentication technology does not ensure complete user authentication or complete protection of your data and hardware.
  Sony assumes no liability for any problems and damages arising out of your use of or inability to use the fingerprint sensor.
- The fingerprint recognition rate depends on your operating conditions and varies among individuals as well.
- Be sure to make a backup copy of the data stored on the built-in storage device, especially in the encrypted archives created with the **File Safe** feature, before sending your computer for repair.
  Sony assumes no liability for any loss or modification of your data that might have occurred during the course of repair.
- In case the built-in storage device has to be initialized, for example after the repair work, the fingerprint templates will be lost. You will have to register them all over again.
- The maintenance and management of data concerning fingerprint authentication must be carried out at your own risk.
  Sony assumes no liability for any defects arising out of your data maintenance and management.
- Before disposing of your computer or transferring it to a third person, it is strongly recommended you erase the fingerprint data registered on the fingerprint sensor after erasing the data stored on your built-in storage device. See **Erasing the Registered Fingerprints** **(page 79)** for the detailed procedure.
- A fingerprint sensor may malfunction or be damaged if you scratch its surface with:
  - a solid or sharp-pointed object
  - fine objects, for example swiping a finger covered with dirt across the fingerprint sensor
- Discharge static electricity from your finger by touching a metallic object especially during dry seasons (e.g. winter) before scanning your fingerprint. Static electricity may cause the fingerprint sensor to malfunction.

Downloaded from LpManual.com Manuals

Using the TPM

Features and options in this section may not be available on your computer.
See the specifications to find out about the configuration of your computer.

- Although your computer is provided with the TPM security functions, these functions do not ensure complete protection of your data and hardware. Sony assumes no liability for any problems and damages arising out of your use of the functions.
- After you have installed the **Infineon TPM Professional Package**, you need to set a few TPM passwords on your computer. Without these passwords, you will not be able to restore any TPM-protected data. Be sure to write down the passwords and keep them safe and private from other people.
- Be sure to make backup copies of the latest emergency recovery archive file, emergency recovery token file, password reset token file, and personal secret file and keep them safe and private from other people before sending your computer for repair. The data stored in the TPM that is embedded on the motherboard may be lost or corrupted during the course of repair.
- During the course of repair, the TPM will also be replaced if the motherboard needs replacement. In such a case, use the backup copies of the emergency recovery archive file, emergency recovery token file, password reset token file, and personal secret file to restore the TPM configuration.
- Be sure to make a backup copy of the data stored on the built-in storage device before sending your computer for repair. The built-in storage device may be initialized and returned after the repair work and, in such a case, you will not be able to restore the data on the device using the backup copies of the emergency recovery archive file, emergency recovery token file, password reset token file, and personal secret file.

Downloaded from LpManual.com Manuals

- Make sure you set up the automatic backup operations after completing the TPM initialization wizard. If the window containing the **Run automatic backup now** check box is displayed after the setup, select the check box and update the backup files. The restore process using the backup files may fail if you do not set up the automatic backup operations.
- The maintenance and management of TPM-protected data must be carried out at your own risk. Sony assumes no liability for any defects arising out of your data maintenance and management.

Downloaded from LpManual.com Manuals

Troubleshooting

This section describes how to solve common problems you might encounter when using your VAIO computer. Many problems have simple solutions. Try these suggestions before contacting VAIO-Link.

Features and options in this section may not be available on your computer.

- **Computer** (page 160)
- **System Security** (page 166)
- **Battery** (page 167)
- **Built-in Camera** (page 169)
- **Internet** (page 171)
- **Networking** (page 173)
- **Bluetooth Technology** (page 178)
- **Optical Discs** (page 182)
- **Display** (page 186)
- **Printing** (page 190)
- **Microphone** (page 192)
- **Speakers** (page 193)
- **Touch Pad** (page 194)
- **Keyboard** (page 195)
- **Floppy Disks** (page 196)

Downloaded from LpManual.com Manuals

- PC Cards (page 197)
- Audio/Video (page 199)
- Memory Stick (page 201)
- Peripherals (page 202)
- Docking Station (page 204)

Downloaded from LpManual.com Manuals

Computer

What should I do if my computer does not start?

- ❑ Make sure your computer is securely plugged into a power source and turned on and the power indicator light is lit.
- ❑ Make sure the battery pack is installed properly and charged.
- ❑ Disconnect all connected USB devices (if any), and then restart your computer.
- ❑ Remove any extra memory modules you may have installed since purchase, and then restart your computer.
- ❑ If your computer is plugged into a power strip or an uninterruptible power supply (UPS), make sure the power strip or UPS is plugged into a power source and turned on.
- ❑ If you are using an external display, make sure it is plugged into a power source and turned on. Make sure the brightness and contrast controls are adjusted correctly. See the manual that came with your display for more information.
- ❑ Unplug the AC adapter and remove the battery pack. Wait three to five minutes. Reinstall the battery pack, plug the AC adapter, and then press the power button to turn on your computer.
- ❑ Condensation may cause your computer to malfunction. If this occurs, do not use the computer for at least one hour.
- ❑ Check that you are using the supplied Sony AC adapter. For your safety, use only the genuine Sony rechargeable battery pack and AC adapter, which are supplied by Sony for your VAIO computer.

Downloaded from LpManual.com Manuals

What should I do if the green power indicator light turns on but my screen remains blank?

- Press the **Alt**+**F4** keys several times to close the application window. An application error may have occurred.
- Press the **Ctrl**+**Alt**+**Delete** keys and click the arrow next to the **Shut down** button and **Restart**.
- Press and hold the power button for more than four seconds to shut down your computer. Unplug the AC adapter and leave the computer for about five minutes. Then plug the AC adapter and turn on the computer again.

  !
  Turning off your computer with the power button or the **Ctrl**+**Alt**+**Delete** keys may cause loss of unsaved data.

What should I do if my computer or software stops responding?

- If your computer stops responding while a software application is running, press the **Alt**+**F4** keys to close the application window.
- If the **Alt**+**F4** keys do not work, click **Start**, the arrow next to the **Lock** button, and **Shut Down** to turn off your computer.
- If your computer does not turn off, press the **Ctrl**+**Alt**+**Delete** keys and click the arrow next to the **Shut down** button and **Shut Down**.
  If the **Windows Security** window appears, click **Shut Down**.
- If your computer still does not turn off, press and hold the power button until the computer turns off.

  !
  Turning off your computer with the **Ctrl**+**Alt**+**Delete** keys or the power button may cause loss of unsaved data.
- Unplug the AC adapter and remove the battery pack. Wait three to five minutes. Reinstall the battery pack, plug the AC adapter, and then press the power button to turn on your computer.
- Try reinstalling the software.
- Contact the software publisher or designated provider for technical support.

Downloaded from LpManual.com Manuals

Why doesn't my computer enter Sleep or Hibernate mode?

Your computer may become unstable if the operating mode is changed before the computer completely enters Sleep or Hibernate mode.

To restore your computer to Normal mode

1. Close all open programs.
2. Click **Start**, the arrow next to the **Lock** button, and **Restart**.
3. If your computer does not restart, press the **Ctrl**+**Alt**+**Delete** keys and click the arrow next to the **Shut down** button and **Restart**.
4. If this procedure does not work, press and hold the power button until the computer turns off.

!
Turning off your computer with the power button may cause loss of unsaved data.

What should I do if the charge indicator light is blinking fast and my computer does not start?

- This problem could be due to the battery pack not being installed properly. To resolve this problem, turn off your computer and remove the battery pack. Then reinstall the battery pack to the computer again. For details, see **Installing the Battery Pack** **(page 19)**.
- If the problem persists after performing the above, it means the installed battery pack is not compatible. Remove the battery pack and contact VAIO-Link.

Downloaded from LpManual.com Manuals

What should I do if a message appears notifying of either incompatibility or the improper installation of the battery pack and my computer then enters Hibernate mode?

- This problem could be due to the battery pack not being installed properly. To resolve this problem, turn off your computer and remove the battery pack. Then reinstall the battery pack to the computer again. For details, see **Installing the Battery Pack** **(page 19)**.
- If the problem persists after performing the above, it means the installed battery pack is not compatible. Remove the battery pack and contact VAIO-Link.

Why does the System Properties window display a slower CPU speed than the maximum?

This is normal. Because your computer's CPU utilizes a type of CPU speed controlling technology for power conservation purposes, System Properties may display the current CPU speed instead of the maximum speed.

What should I do if my computer does not accept my password and returns a message, Enter Onetime Password?

If you enter a wrong power-on password three times consecutively, the **Enter Onetime Password** message appears and Windows will not start. Press and hold the power button for more than four seconds to check that the power indicator light turns off. Wait for 10 or 15 seconds, then restart your computer and enter the correct password. When entering the password, check that the Num lock and Caps lock indicators are unlit. If both or either of the lights is lit, press the **Num Lk** (or **Num Lock**) key or the **Caps Lock** key to turn off the indicator before entering the password.

Downloaded from LpManual.com Manuals

What should I do if my game software does not work or it keeps crashing?

- Check the web site of the game if there are any patches or updates to download.
- Make sure you have installed the latest video driver software.
- On some VAIO models, the graphics memory is shared with the system. The optimal graphic performance in this case is not guaranteed.

What should I do if I cannot remember the power-on password?

If you have forgotten the power-on password, contact VAIO-Link to reset it. A reset fee will be charged.

Why doesn't my screen turn off after the automatic turn-off time has passed?

The VAIO original screen saver disables the timer setting, which you can select using the Windows power options, for your screen to turn off.
Select a screen saver other than the VAIO original screen saver.

Downloaded from LpManual.com Manuals

How can I change the boot device order?

You can use one of the BIOS functions to change the boot device order. Follow these steps:

1. Turn on your computer.
2. Press the **F2** key when the VAIO logo appears.
   The BIOS setup screen appears. If not, restart the computer and press the **F2** key several times when the VAIO logo appears.
3. Press the ← or → key to select **Boot**.
4. Press the ↑ or ↓ key to select the drive whose boot device order you want to change.
5. Press the **F5** or **F6** key to change the boot device order.
6. Press the ← or → key to select **Exit**, select **Exit Setup**, and then press the **Enter** key.
   At the confirmation prompt, press the **Enter** key.

What should I do if I cannot boot my computer from the USB floppy disk drive connected to the computer?

To boot your computer from the USB floppy disk drive, you need to change the boot device.

Turn on your computer and press the **F11** key when the VAIO logo appears.

How do I check the volume of the recovery partition?

Your built-in storage device contains the recovery partition where the data for the system recovery is stored. To check the volume of the recovery partition, follow these steps:

1. Click **Start**, right-click **Computer**, and select **Manage**.
2. Click **Disk Management** under **Storage** in the left pane.
   The volume of the recovery partition and the total volume of the C drive are displayed in the **Disk 0** row in the center pane.

Downloaded from LpManual.com Manuals

System Security

How can I protect my computer against security threats, such as viruses?

The Microsoft Windows operating system is preinstalled on your computer. The best way to protect your computer against security threats, such as viruses, is to download and install the latest Windows updates regularly.

You can get important Windows updates by doing the following:

! Your computer must be connected to the Internet to download the updates.

1 Connect to the Internet.

2 Double-click the **Windows Security Alerts** icon on the taskbar.

3 Follow the on-screen instructions to set up automatic or scheduled updates.

How do I keep my antivirus software updated?

You can keep the **McAfee** software program current with the latest updates from McAfee, Inc.

To download and install the latest security updates, follow these steps:

! Your computer must be connected to the Internet to download the updates.

1 Click **Start**, **All Programs**, **McAfee**, and **McAfee SecurityCenter**.

2 Click the button located at the upper left corner of the window to update the software.

3 Follow the on-screen instructions to download updates.

See the help file included with your software program for more information.

Downloaded from LpManual.com Manuals

Battery

How do I find the battery charging status?

You can check the charge indicator for the battery charging status. See **Charging the Battery Pack (page 22)** for more information.

When is my computer using AC power?

When your computer is directly connected to the AC adapter, it uses AC power, even if the battery pack is installed.

When should I recharge the battery pack?

- When the battery charge level falls below 10%.
- When both the charge and power indicator lights blink.
- When you have not used the battery pack for a long period of time.

When should I replace the battery pack?

If the battery pack quickly runs out of power after fully charged, it may be reaching the end of its life and should be replaced.

To check the battery charge capacity, see **To check the battery charge capacity (page 24)**.

Downloaded from LpManual.com Manuals

Should I be concerned that the installed battery pack is warm?

No, it is normal for the battery pack to be warm when it is powering your computer.

Can my computer enter Hibernate mode while using battery power?

Your computer can enter Hibernate mode while using battery power, but some software programs and peripheral devices prevent the system from entering Hibernate mode. If you are using a program that prevents the system from entering Hibernate mode, save your data frequently to avoid losing data. See **Using Hibernate Mode** **(page 126)** for information on how you can manually activate Hibernate mode.

Downloaded from LpManual.com Manuals

Built-in Camera

Why does the viewfinder show no images or poor-quality images?

- The built-in camera cannot be shared by more than one software application. Exit the current application before launching another.
- The viewfinder may show some noise, for example horizontal streaks, if you view a rapid-moving object. This is normal and does not indicate a malfunction.
- If the problem persists, restart your computer.

Why are captured images poor in quality?

- The images captured under the fluorescent light may show reflections of light.
- A dark portion in captured images may appear as a noise.
- If the lens protection cover is dirty, you cannot take a clear shot. Clean the cover. See **Handling the Built-in Camera (page 149)**.

What should I do if captured images contain dropped frames and audio interruptions?

- The effect settings on your software application may cause dropped frames. See the help file included with your software application for more information.
- There may be more software applications running than your computer can handle. Exit the applications that you are not currently using.
- The power management function of your computer may be active. Check the CPU performance.

Downloaded from LpManual.com Manuals

What should I do if movie playback shows dropped frames when my computer is running on the battery?

The battery pack is running out of power. Connect your computer to an AC power source.

What should I do if captured images flicker?

This problem occurs when you use the camera under fluorescent lights due to the mismatch between lighting output frequency and shutter speed.
To reduce flicker noise, change the direction of the camera or the brightness of camera images. In some software applications, you can set an appropriate value to one of the camera properties (e.g. light source, flicker, etc.) to eliminate flicker noise.

Why is the video input from the built-in camera suspended for a few seconds?

The video input may be suspended for a few seconds if:

- a shortcut key with the **Fn** key is used.
- the CPU load increases.

This is normal and does not indicate a malfunction.

What should I do if my computer becomes unstable when it enters a power saving mode while the built-in camera is in use?

If your computer automatically enters Sleep or Hibernate mode, change the corresponding power saving mode setting. To change the setting, see **Using the Power Saving Modes** **(page 123)**.

Downloaded from LpManual.com Manuals

Internet

What should I do if my modem does not work?

- Make sure the telephone cable is securely plugged into the modem port on your computer and the wall jack.
- Make sure the telephone cable is working. Plug the cable into an ordinary telephone and listen for a dial tone.
- Make sure that the telephone number the program is dialing is correct.
- Make sure the software you are using is compatible with your computer's modem. (All preinstalled Sony programs are compatible.)
- Make sure the modem is the only device connected to your telephone line.
- Follow these steps to check the settings:
  1. Click **Start** and **Control Panel**.
  2. Click **Hardware and Sound**.
  3. Click **Phone and Modem Options**.
  4. On the **Modems** tab, check that your modem is listed.
  5. On the **Dialing Rules** tab, check the location information is correct.

Downloaded from LpManual.com Manuals

Why is my modem connection slow?

Your computer is equipped with a V.92/V.90 compatible modem. Many factors may influence modem connection speed, including telephone line noise or compatibility with telephone equipment, such as fax machines or other modems. If you think your modem is not connecting properly to other PC-based modems, fax machines, or your ISP, do any of the following:

- Ask your telephone company to verify your telephone line is free of any line noise.
- If your problem is fax-related, make sure there are no problems with the fax machine you are calling and that it is compatible with fax modems.
- If you are having a problem connecting with your ISP, make sure the ISP is not experiencing technical problems.
- If you have a second telephone line, try connecting the modem to that line.

Downloaded from LpManual.com Manuals

Networking

What should I do if my computer cannot connect to a wireless LAN access point?

- Connection capability is affected by distance and obstructions. You may need to move your computer away from obstructions or closer to any access point you may be using.
- Make sure the **WIRELESS** switch is on and the **WIRELESS** indicator light is lit on your computer.
- Make sure power to the access point is on.
- If you want to connect your computer to a wireless LAN access point using the 5 GHz band, make sure the option to use the 5 GHz band or both the 2.4 GHz and 5 GHz bands is selected on the **WLAN** tab in the **VAIO Smart Network** settings window. Wireless LAN communication (IEEE 802.11a standard) using only the 5 GHz band, available on selected models only, is disabled by default.
- Follow these steps to check the settings:
  1. Click **Start** and **Control Panel**.
  2. Click **View network status and tasks** under **Network and Internet**.
  3. Click **Connect to a network** to confirm that your access point is selected.
- Make sure the encryption key is correct.

Downloaded from LpManual.com Manuals

- Make sure **Maximum Performance** is selected for **Wireless Adapter Settings** in the **Power Options** window. Selecting any other option may result in a communication failure. To change the settings, follow these steps:
  1. Right-click the power status icon on the taskbar and select **Power Options**.
  2. Click **Change plan settings** under the current power plan.
  3. Click **Change advanced power settings**.
  4. Select the **Advanced settings** tab.
  5. Double-click **Wireless Adapter Settings** and **Power Saving Mode**.
  6. Select **Maximum Performance** from the drop-down list both for **On battery** and **Plugged in**.
- If you have disabled the wireless LAN function in the BIOS setup screen, you cannot connect to wireless access points. To enable the function, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

Downloaded from LpManual.com Manuals

What should I do if I cannot access the Internet?

- Check the access point settings. See the manual that came with your access point for more information.
- Make sure your computer and the access point are connected to one another.
- Move your computer away from obstacles or closer to any access point you may be using.
- Make sure your computer is properly configured for Internet access.
- Make sure **Maximum Performance** is selected for **Wireless Adapter Settings** in the **Power Options** window. Selecting any other option may result in a communication failure. Follow the steps in **What should I do if my computer cannot connect to a wireless LAN access point? (page 173)** to change the settings.
- If you have disabled the wireless LAN function or the network (Ethernet) port in the BIOS setup screen, you cannot access the Internet through a wireless or Ethernet network. To enable the function or the port, follow the steps and the tip in **Disabling Built-in Devices (page 130)**.

Why is the data transfer speed slow?

- The wireless LAN data transfer speed is affected by distance and obstructions between devices and access points. Other factors include device configurations, radio conditions, and software compatibility. To maximize the data transfer speed, move your computer away from obstacles or closer to any access point you may be using.
- If you are using a wireless LAN access point, the device may be temporarily overloaded depending on how many other devices are communicating via the access point.
- If your access point interferes with other access points, change the access point channel. See the manual that came with your access point for more information.
- Make sure **Maximum Performance** is selected for **Wireless Adapter Settings** in the **Power Options** window. Selecting any other option may result in a communication failure. Follow the steps in **What should I do if my computer cannot connect to a wireless LAN access point? (page 173)** to change the settings.

Downloaded from LpManual.com Manuals

How do I avoid data transfer interruptions?

- When your computer is connected to an access point, data transfer interruptions may occur if a large file is exchanged or the computer is placed in close proximity to microwaves and cordless telephones.
- Move your computer closer to the access point.
- Make sure the access point connection is intact.
- Change the access point channel. See the manual that came with your access point for more information.
- Make sure **Maximum Performance** is selected for **Wireless Adapter Settings** in the **Power Options** window. Selecting any other option may result in a communication failure. Follow the steps in **What should I do if my computer cannot connect to a wireless LAN access point?** **(page 173)** to change the settings.

What are channels?

- Wireless LAN communication uses divided frequency bands known as channels. Third-party wireless LAN access point channels may be preset to different channels from Sony devices.
- If you are using a wireless LAN access point, see connectivity information contained in the manual that came with your access point.

Why does the network connection stop when I change the encryption key?

Two computers with the wireless LAN function may lose a peer-to-peer network connection if the encryption key is changed. You can either change the encryption key back to the original profile or re-enter the key on both computers so the key matches.

Downloaded from LpManual.com Manuals

How do I display the VAIO Smart Network window?

To display the **VAIO Smart Network** window on the desktop, follow these steps:

1. Click **Start**, **All Programs**, and **VAIO Control Center**.
2. Click **Network Connections** and **VAIO Smart Network**.
3. Click **Advanced** in the right pane.

✍
For information on the **VAIO Smart Network** software, see the help file included with the software.

Downloaded from LpManual.com Manuals

Bluetooth Technology

What should I do if other Bluetooth devices cannot find my computer?

- Make sure both devices have the Bluetooth function enabled.
- Make sure the **WIRELESS** switch is on and the **WIRELESS** indicator light is lit on your computer.
- You cannot use the Bluetooth function when your computer is in a power saving mode. Bring the computer back to Normal mode, then turn on the **WIRELESS** switch.
- Your computer and the device may be too far apart. Wireless Bluetooth technology works best when the devices are within 10 meters of each other.

What should I do if I cannot find the Bluetooth device I want to communicate with?

- Check that the Bluetooth function of the device you want to communicate with is on. See the other device's manual for more information.
- If the device you want to communicate with is already communicating with another Bluetooth device, it may not be found or it may not be able to communicate with your computer.
- To allow other Bluetooth devices to communicate with your computer, follow these steps:

  1 Click **Start**, **Control Panel**, **Hardware and Sound**, **Bluetooth Devices**, and **Bluetooth Settings**.

  2 Click the **Options** tab and select the **Allow Bluetooth devices to find this computer** check box.

Downloaded from LpManual.com Manuals

What should I do if other Bluetooth devices cannot connect to my computer?

- Check the suggestions in **What should I do if I cannot find the Bluetooth device I want to communicate with? (page 178)**.
- Make sure the other devices are authenticated.
- The data transfer distance can be shorter than 10 meters depending on existing obstacles between the two devices, on radio wave quality, and on the operating system or the software in use. Move your computer and Bluetooth devices closer to each other.

Why is my Bluetooth connection slow?

- The data transfer speed depends on the obstructions and/or the distance between the two devices, on the radio wave quality, and on the operating system or the software in use. Move your computer and Bluetooth devices closer to each other.
- The 2.4 GHz radio frequency used by Bluetooth and wireless LAN devices is also used by other devices. Bluetooth devices incorporate technology that minimizes interference from other devices using the same wavelength, however, communication speed and connection range may be reduced. Interference from other devices may also stop communications altogether.
- Connection capability is affected by distance and obstructions. You may need to move your computer away from obstacles or closer to the device to which it is connected.
- Identify and remove obstacles between your computer and the device to which it is connected.

Why can't I use the services supported by the connected Bluetooth device?

Connection is only possible for services also supported by the computer with the Bluetooth function. For more details, search for Bluetooth information using **Windows Help and Support**.

Downloaded from LpManual.com Manuals

Can I use a device with Bluetooth technology on airplanes?

With Bluetooth technology, your computer transmits a radio frequency of 2.4 GHz. Sensitive locations, such as hospitals and airplanes, may have restrictions on use of Bluetooth devices to avoid radio interference. Check with facility staff to see if use of the Bluetooth function on the computer is permitted.

Why can't I use the Bluetooth function when I log onto my computer as a user with a standard user account?

The Bluetooth function may not be available to a user with a standard user account on your computer. Log onto the computer as a user with administrative rights.

Why can't I use the Bluetooth devices when I switch users?

If you switch users without logging off your system, the Bluetooth devices will not work. Be sure to log off before switching users. To log off your system, click **Start**, the arrow next to the **Lock** button, and **Log Off**.

Why can't I exchange business card data with a mobile phone?

The business card exchange function is not supported.

Downloaded from LpManual.com Manuals

What should I do if I do not hear sound from my headphones or audio/video controller?

Check the SCMS-T settings. If your headphones or audio/video controller does not support SCMS-T content protection, you need to connect the device using the Advanced Audio Distribution Profile (A2DP). Follow these steps:

1. Click **Start**, **Control Panel**, **Hardware and Sound**, and **Bluetooth Devices**.
2. Right-click the icon for the device that you want to connect using the A2DP and select **Control**.
3. Click to cancel the **Connect to a device only if it supports SCMS-T content protection** check box under **SCMS-T Settings**.

Downloaded from LpManual.com Manuals

Optical Discs

Why does my computer freeze when I try to read a disc?

The disc that your computer is trying to read may be dirty or damaged. Follow these steps:

1 Press the **Ctrl**+**Alt**+**Delete** keys and click the arrow next to the **Shut down** button and **Restart** to restart the computer.

2 Remove the disc from the optical disc drive.

3 Check the disc for dirt or damage. If you need to clean the disc, see **Handling Discs** **(page 150)** for instructions.

What should I do if the drive tray does not open?

- ❑ Make sure your computer is on.
- ❑ Press the drive eject button.
- ❑ The optical disc drive on your computer may have been disabled in the BIOS setup screen. Follow the steps and the tip in **Disabling Built-in Devices** **(page 130)** to enable the drive.
- ❑ If the drive eject button does not work, click **Start** and **Computer**, right-click the optical disc drive icon, and select **Eject**.
- ❑ If none of the above options work, insert a thin, straight object (such as a paper clip) into the manual eject hole on the optical disc drive.
- ❑ Try restarting your computer.

Downloaded from LpManual.com Manuals

What should I do if I cannot play a disc properly on my computer?

- Make sure the disc is inserted into the optical disc drive with the label facing upward.
- Make sure the necessary program(s) is installed according to the manufacturer's instructions.
- If a disc is dirty or damaged, your computer will stop responding. Follow these steps:
  1. Press the **Ctrl**+**Alt**+**Delete** keys and click the arrow next to the **Shut down** button and **Restart** to restart the computer.
  2. Remove the disc from the optical disc drive.
  3. Check the disc for dirt or damage. If you need to clean the disc, see **Handling Discs** **(page 150)** for instructions.
- If you are playing a disc and cannot hear sound, do any of the following:
  - The volume may have been turned off by the muting button. Press the button once again.
  - The volume may have been minimized by the **Fn**+**F3** keys. Keep pressing the **Fn**+**F4** keys to turn up the volume loud enough to hear sound.
  - Right-click the volume icon on the taskbar and click **Open Volume Mixer** to check the settings.
  - Check the volume setting in the audio mixer.
  - If you are using external speakers, check the volume settings on the speakers and the connections between the speakers and your computer.

Downloaded from LpManual.com Manuals

- ❑ Make sure the correct driver software is installed. Follow these steps:

1. Click **Start** and **Control Panel**.
2. Click **System and Maintenance**.
3. Click **System**.
4. Click **Device Manager** in the left pane.
   The **Device Manager** window appears with a listing of your computer's hardware devices.
   If an "X" or an exclamation point appears on the listed device, you may need to enable the device or reinstall the driver software.
5. Double-click the optical disc drive device to open a list of the optical disc drives of your computer.
6. Double-click the desired drive.
   You can confirm the driver software by selecting the **Driver** tab, and clicking **Driver Details**.
7. Click **OK** to close the window.

- ❑ Make sure an adhesive label is not affixed to a disc. Adhesive labels can come off while the disc is in the optical disc drive and damage the drive or cause it to malfunction.
- ❑ If a region code warning appears, the disc may be incompatible with the optical disc drive. Check the package to make sure the region code is compatible with the optical disc drive.
- ❑ If you notice condensation on your computer, do not use the computer for at least one hour. Condensation can cause the computer to malfunction.
- ❑ Make sure your computer is running on the AC power supply and try the disc again.

Downloaded from LpManual.com Manuals

What should I do if I cannot write data to CD media?

- Make sure you neither launch any software application nor allow any to launch automatically, not even a screen saver.
- If you are using a CD-R/RW disc with an adhesive label affixed, replace it with one with no affixed adhesive label. Using a disc with an affixed adhesive label could cause a write error or other damage.

What should I do if I cannot write data to DVD media?

- Make sure you are using the correct DVD recordable media.
- Check which DVD recordable format is compatible with your optical disc drive. Some brands of DVD recordable media do not work.

What should I do if I cannot play discs?

The optical disc drive on your computer may have been disabled in the BIOS setup screen. Follow the steps and the tip in **Disabling Built-in Devices** **(page 130)** to enable the drive.

Downloaded from LpManual.com Manuals

Display

Why did my screen go blank?

- Your computer screen may go blank if the computer loses power or enters a power saving mode (Sleep or Hibernate). If the computer is in LCD (Video) Sleep mode, press any key to bring the computer back into Normal mode. See **Using the Power Saving Modes** **(page 123)** for more information.
- Make sure your computer is securely plugged into a power source and turned on and the power indicator light is lit.
- If your computer is using battery power, make sure the battery pack is installed properly and is charged. See **Using the Battery Pack** **(page 19)** for more information.
- If the display output is directed to the external display, press the **Fn**+**F7** keys. See **Combinations and Functions with the Fn Key** **(page 29)** for more information.

What should I do if I do not see proper images or videos?

- Be sure to select **Highest (32 bit)** for the display colors before using video/image software or starting DVD playback. Selecting any other option may prevent such software from displaying images successfully. To change the display colors, follow these steps:

  1 Right-click on the desktop and select **Personalize**.

  2 Click **Display Settings**.

  3 Select **Highest (32 bit)** under **Colors**.

- Do not change the display resolution or colors while using video/image software or playing DVDs, as it may cause unsuccessful playback/display or unstable system operations.
  Additionally, it is recommended you disable your screen saver before starting DVD playback. If the screen saver is enabled, it may be activated during DVD playback and prevent it from running successfully. Some screen savers have been found to even change the display resolution and colors.

Downloaded from LpManual.com Manuals

Why doesn't my screen display a video?

- If the display output is directed to the external display and the external display is disconnected, you cannot display a video on your computer screen. Stop video playback, change the display output to the computer screen, and then restart video playback. See **Selecting Display Modes** **(page 100)** for changing the display output. Alternatively, you can press the **Fn**+**F7** keys to change the display output. See **Combinations and Functions with the Fn Key** **(page 29)** for more information.
- The video memory of your computer may be insufficient for displaying high resolution videos. In this case, lower the resolution of the LCD screen.

  To change the screen resolution, follow these steps:

  1. Right-click on the desktop and select **Personalize**.
  2. Click **Display Settings**.
  3. Move the slider under **Resolution** to the left to reduce or to the right to increase the screen resolution.

  ✍
  You can check the total amount of the graphics and video memory available. Right-click on the desktop, select **Personalize**, and click **Display Settings**, **Advanced Settings**, and the **Adaptor** tab. The displayed value may be different from the actual amount of memory on your computer.

What should I do if my screen is dark?

Press the **Fn**+**F6** keys to brighten your computer screen.

Downloaded from LpManual.com Manuals

What should I do if the LCD brightness of my screen changes?

The LCD brightness setting, adjusted with the **Fn**+**F5**/**F6** keys, is temporary and may be restored to the original setting when your computer returns to Normal mode from Sleep or Hibernate mode. To save your preference for the brightness, follow these steps:

1. Right-click the power status icon on the taskbar and select **Power Options**.
2. Click **Change plan settings** under the current power plan.
3. Click **Change advanced power settings**.
4. Select the **Advanced settings** tab.
5. Double-click **Display**.
6. Adjust the LCD brightness setting in the item for brightness adjustment.

What should I do if the external display remains blank?

If you cannot change the display output with the **Fn**+**F7** keys, you need to change the settings for the external display with the **VAIO Control Center**. To change the settings, launch the **VAIO Control Center**, select the control item for the external display, and then click to select the check box for changing the options to detect the external display. Then, use the **Fn**+**F7** keys to change the display output.

Downloaded from LpManual.com Manuals

How do I run Windows Aero?

To run Windows Aero, follow these steps:

1 Click **Start** and **Control Panel**.

2 Click **Customize colors** under **Appearance and Personalization**.

3 Click **Open classic appearance properties for more color options**.

4 Select **Windows Aero** from the **Color scheme** options on the **Appearance** tab.

5 Click **OK**.

For information about the Windows Aero features, such as Windows Flip 3D, see **Windows Help and Support**.

Downloaded from LpManual.com Manuals

Printing

What should I do if I cannot print a document?

- Make sure your printer is on, and the printer cable is securely connected to the ports on the printer and your computer.
- Make sure your printer is compatible with the Windows operating system installed on your computer.
- You may need to install the printer driver software before you use your printer. See the manual that came with your printer for more information.
- If your printer is not functioning after your computer resumes from a power saving mode (Sleep or Hibernate), then restart the computer.
- If the bidirectional communication functions are provided with your printer, disabling the functions on your computer may enable printing. Follow these steps:

  1 Click **Start** and **Control Panel**.

  2 Click **Printer** under **Hardware and Sound**.

  3 Right-click the printer icon and select **Properties**.

  4 Click the **Ports** tab.

  5 Click to cancel the **Enable bidirectional support** check box.

  6 Click **OK**.

  This disables the bidirectional communication functions of the printer, such as data transfer, status monitoring, and remote panel.

  When your printer is connected to the optional docking station, check to see if the docking station is connected to an AC power source.

Downloaded from LpManual.com Manuals

- If you have disabled the USB ports in the BIOS setup screen, you cannot use the printer connected to one of the USB ports on your computer. To enable the ports, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.
- If the use of USB ports is restricted by the **USB Access Restriction Setting** utility, you cannot use the printer connected to one of the USB ports on your computer. To change the setting, see **Restricting USB Access** **(page 132)**.

Downloaded from LpManual.com Manuals

Microphone

What should I do if my microphone does not work?

If you are using an external microphone, make sure the microphone is turned on and is properly plugged into the microphone jack on your computer.

How can I prevent microphone feedback?

Microphone feedback occurs when the microphone receives the sound from a sound output device, such as a speaker.

To prevent this problem:

- Keep the microphone away from a sound output device.
- Turn down the volume of the speakers and the microphone.

Downloaded from LpManual.com Manuals

Speakers

What should I do if I do not hear sound from the built-in speakers?

- If you are using a program that has its own volume control, make sure the volume control is properly set. See the program's help file for more information.
- The volume may have been turned off by the muting button. Press the button once again.
- The volume may have been minimized by the **Fn**+**F3** keys. Keep pressing the **Fn**+**F4** keys to turn up the volume loud enough to hear sound.
- Check the Windows volume controls by clicking the volume icon on the taskbar.

What should I do if my external speakers do not work?

- Check the suggestions in **What should I do if I do not hear sound from the built-in speakers?** **(page 193)**.
- Make sure your speakers are properly connected and the volume is turned up loud enough to hear sound.
- Make sure your speakers are designed for computer use.
- If your speakers have a muting button, set the button to off.
- If your speakers require external power, make sure the speakers are connected to a power source. See the manual that came with your speakers for more information.

Downloaded from LpManual.com Manuals

Touch Pad

What should I do if the touch pad does not work?

- You may have disabled the touch pad before connecting a mouse to your computer. See **Using the Touch Pad** **(page 31)**.
- Make sure that a mouse is not connected to your computer.
- If the pointer does not move while a software application is running, press the **Alt**+**F4** keys to close the application window.
- If the **Alt**+**F4** keys do not work, press the Windows key once and then the ➡ key several times, select **Restart** with the ⬆ or ⬇ key, and press the **Enter** key to restart your computer.
- If your computer does not restart, press the **Ctrl**+**Alt**+**Delete** keys, select the arrow next to the **Shut down** button with the ⬇ and ➡ keys and then **Restart** with the ⬆ or ⬇ key, and press the **Enter** key to restart your computer.
- If this procedure does not work, press and hold the power button until the computer turns off.

!
Turning off your computer with the power button may cause loss of unsaved data.

Downloaded from LpManual.com Manuals

Keyboard

What should I do if the keyboard configuration is wrong?

The language layout of your computer's keyboard is labeled on the packaging box. If you choose a different regional keyboard when you complete the Windows setup, the key configuration will be mismatched.
To change the keyboard configuration, follow these steps:

1 Click **Start** and **Control Panel**.

2 Click **Clock, Language, and Region**, and click **Regional and Language Options**.

3 Change the settings as desired.

What should I do if I cannot enter certain characters with the keyboard?

If you cannot enter **U**, **I**, **O**, **P**, **J**, **K**, **L**, **M**, and so on, the **Num Lk** key may be activated. Check that the Num lock indicator light is unlit. If the Num lock indicator is lit, press the **Num Lk** key to turn it off before entering these characters.

Downloaded from LpManual.com Manuals

Floppy Disks

Why doesn't the Safely Remove Hardware icon appear on the taskbar when the drive is connected?

Your computer does not recognize the floppy disk drive. First, make sure the USB cable is properly connected to the USB port. If you need to secure the connection, wait a few moments for the computer to recognize the drive. If the icon still does not appear, follow these steps:

1. Close all programs that are accessing the floppy disk drive.
2. Wait until the indicator light on the floppy disk drive turns off.
3. Push the eject button to remove the disk, and disconnect the USB floppy disk drive from your computer.
4. Reconnect the floppy disk drive by plugging the USB cable into the USB port.
5. Restart the computer by clicking **Start**, the arrow next to the **Lock** button, and **Restart**.

What should I do if I cannot write data to a floppy disk?

- Make sure the floppy disk is properly inserted in the drive.
- If the disk is inserted properly and you are still unable to write data to it, the disk may be full or write-protected. You can either use a floppy disk that is not write-protected or disable the write-protect feature.
- If you have disabled the USB ports in the BIOS setup screen, you cannot write data to the floppy disk in the external disk drive connected to one of the USB ports on your computer. To enable the ports, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.
- If you have restricted the use of USB ports with the **USB Access Restriction Setting** utility, you cannot write data to the floppy disk in the external floppy disk drive connected to one of the USB ports on your computer. To change the setting, see **Restricting USB Access** **(page 132)**.

Downloaded from LpManual.com Manuals

PC Cards

What should I do if my PC Card does not work?

- Make sure the PC Card is inserted properly. See **Using the PC Card** **(page 49)** for more information.
- Make sure the PC Card is compatible with the Microsoft Windows operating system installed on your computer.
- See the manual that came with your PC Card for more information. You may need to install driver software if you are not using a Sony PC Card.
- If your PC Card, which worked normally before, does not work, you may need to install the most recent driver software. Follow these steps:
  1. Click **Start** and **Control Panel**.
  2. Click **System and Maintenance**.
  3. Click **System**.
  4. Click **Device Manager** on the left pane.
     The **Device Manager** window appears.
  5. Double-click the device name for the PC Card to display the properties window.
  6. Select the **Driver** tab and click **Update Driver**.
- If you have disabled the PC Card slot in the BIOS setup screen, you cannot use the PC Card in the slot. To enable the slot, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

Downloaded from LpManual.com Manuals

Why doesn't my computer recognize connected devices?

- For some PC Cards, if you alternate between Normal mode and Sleep or Hibernate mode while the card is inserted into the **PC Card** slot, your computer may not recognize the PC Card or the connected device. Restart the computer.
- If you have disabled the PC Card slot in the BIOS setup screen, your computer cannot recognize the device connected through the PC Card. To enable the slot, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

Why can't I insert my PC Card?

- Make sure you are inserting the card correctly. See **Using the PC Card** **(page 49)** for more information.
- You may not be able to use some PC Cards or some functions of the PC Card on your computer. See the manual that came with your PC Card for more information.

Downloaded from LpManual.com Manuals

Audio/Video

What should I do if I cannot use my digital video camcorder?

- If a message appears stating that the i.LINK device is disconnected or turned off, the i.LINK cable may not be securely plugged into the port on your computer or camcorder. Unplug the cable, and plug it in once again. See **Connecting an i.LINK Device** **(page 107)** for more information.
- If you have disabled the i.LINK port in the BIOS setup screen, you cannot use the device connected to the i.LINK port. To enable the port, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

How do I turn off the Windows startup sound?

To turn off the Windows startup sound, follow these steps:

1. Click **Start** and **Control Panel**.
2. Click **Hardware and Sound**.
3. Click **Manage audio devices** under **Sound**.
4. On the **Sounds** tab, click to cancel the **Play Windows Startup sound** check box.
5. Click **OK**.

Downloaded from LpManual.com Manuals

How do I change the sound output device?

If you do not hear sound from the device connected to a port, such as the USB port, HDMI output port, optical output port, or headphones jack, you need to change the device for sound output.

1 Close all open programs.

2 Click **Start** and **Control Panel**.

3 Click **Hardware and Sound**.

4 Click **Manage audio devices** under **Sound**.

5 On the **Playback** tab, select the desired device for sound output and click **Set Default**.

What should I do if I do not hear the sound from the sound output device connected to the HDMI output port, optical output port, or headphones jack?

You need to change the sound output device if you want to hear sound from the device connected to a port, such as the HDMI output port, optical output port, or headphones jack. For the detailed procedure, see **How do I change the sound output device?** **(page 200)**.

Why do sound interruptions and/or dropped frames occur when I play high-definition videos, such as those recorded with the AVCHD digital video camcorder?

Playing high-definition videos requires substantial hardware resources, such as CPU, GPU, or system memory performance on your computer. During the video playback, some operations and/or functions may become unavailable, and sound interruptions, dropped frames, and playback failure may occur depending on the configuration of your computer.

Downloaded from LpManual.com Manuals

Memory Stick

What should I do if I cannot use a Memory Stick that was formatted on a VAIO computer on other devices?

You may need to reformat your Memory Stick.

Formatting a Memory Stick erases all data, including music data previously saved on it. Before you reformat a Memory Stick, back up important data and confirm that the Memory Stick does not contain files you want to keep.

1 Copy the data from the Memory Stick onto your built-in storage device to save data or images.

2 Format the Memory Stick by following the steps in **Formatting a Memory Stick** **(page 47)**.

Can I copy images from a digital camera using a Memory Stick?

Yes, and you can view video clips that you have recorded with Memory Stick-compatible digital cameras.

Why can't I write data to a Memory Stick?

- Some versions of the Memory Stick are equipped with an erasure prevention switch to protect data from accidental erasure or overwriting. Make sure the erasure prevention switch is off.
- If you have disabled the Memory Stick slot in the BIOS setup screen, you cannot use the Memory Stick in the slot. To enable the slot, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.

Downloaded from LpManual.com Manuals

Peripherals

What should I do if I cannot connect a USB device?

- If applicable, check the USB device is turned on and using its own power supply. For example, if you are using a digital camera, check if the battery is charged. If you are using a printer, check if the power cable is connected properly to the AC outlet.
- Try using another USB port on your computer. The driver software could be installed to the specific port you used the first time you connected the device.
- See the manual that came with your USB device for more information. You may need to install software before you connect the device.
- Try connecting a simple, low-powered device such as a mouse to test if the port is working at all.
- USB hubs may prevent a device from working because of a power distribution failure. We recommend you connect the device directly to your computer without a hub.
- If you have disabled the USB ports in the BIOS setup screen, you cannot use any connected USB devices. To enable the ports, follow the steps and the tip in **Disabling Built-in Devices** **(page 130)**.
- If the use of USB ports is restricted by the **USB Access Restriction Setting** utility, you cannot use any connected USB devices. To change the setting, see **Restricting USB Access** **(page 132)**.

Downloaded from LpManual.com Manuals

What should I do if I cannot use a peripheral device?

The following built-in devices on your computer may have been disabled in the BIOS setup screen:

- USB ports
- PC Card slot
- i.LINK port

Follow the steps and the tip in **Disabling Built-in Devices** **(page 130)** to enable your desired port(s) or slot(s).

Downloaded from LpManual.com Manuals

Docking Station

What should I do if an error message appears when I disconnect my computer from the docking station?

- When any device inserted or connected to the docking station is in use, you cannot disconnect your computer from the docking station. Save unsaved data, exit applications that are using such devices, and then try again.
  If the above does not work, shut down your computer and disconnect it from the docking station.
- When the battery pack is running out of power, you cannot disconnect your computer from the docking station. Charge the battery pack or shut down the computer and then try again.
- Be sure to return to the originally logged on user before disconnecting your computer from the docking station. Disconnecting it as any other user may cause malfunctions.
  For switching users, see **Windows Help and Support**.

Downloaded from LpManual.com Manuals

Trademarks

Sony, VAIO, the VAIO logo, VAIO Control Center, VAIO Power Management, VAIO Power Management Viewer, VAIO Update, and "BRAVIA" are trademarks or registered trademarks of Sony Corporation.

and "Memory Stick," "Memory Stick Duo," "MagicGate," "OpenMG," "MagicGate Memory Stick," "Memory Stick PRO," "Memory Stick PRO-HG," "Memory Stick Micro," "M2," and the Memory Stick logo are trademarks or registered trademarks of Sony Corporation.

Walkman is a registered trademark of Sony Corporation.

Blu-ray Disc™ and the Blu-ray Disc logo are trademarks of the Blu-ray Disc Association.

Intel, Pentium, Intel SpeedStep, and Atom are trademarks or registered trademarks of Intel Corporation.

Microsoft Windows Vista, the Windows logo, and BitLocker are trademarks or registered trademarks of Microsoft Corporation in the U.S. and other countries.

i.LINK is a trademark of Sony used only to designate that a product contains an IEEE 1394 connection.

Roxio Easy Media Creator is a trademark of Sonic Solutions.

WinDVD for VAIO and WinDVD BD for VAIO are trademarks of InterVideo, Inc.

ArcSoft and the ArcSoft logo are registered trademarks of ArcSoft, Inc. ArcSoft WebCam Companion is a trademark of ArcSoft, Inc.

ATI and ATI Catalyst are trademarks of Advanced Micro Devices, Inc.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license. Other trademarks and trade names are those of their respective owners.

Downloaded from LpManual.com Manuals

The ExpressCard word mark and logos are owned by the PCMCIA and any use of such marks by Sony Corporation is under license. Other trademarks and trade names are those of their respective owners.

SD Logo is a trademark.

SDHC Logo is a trademark.

CompactFlash® is a trademark of SanDisk Corporation.

MultiMediaCard™ is a trademark of MultiMediaCard Association.

HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

"PlaceEngine" is a registered trademark of Koozyt, Inc.

"PlaceEngine" was developed by Sony Computer Science Laboratories, Inc. and is licensed by Koozyt, Inc.

, "XMB," and "xross media bar" are trademarks of Sony Corporation and Sony Computer Entertainment Inc.

"AVCHD" is a trademark of Panasonic Corporation and Sony Corporation.

All other names of systems, products, and services are trademarks of their respective owners. In the manual, the ™ or ® marks are not specified.

Specifications are subject to change without notice. All other trademarks are trademarks of their respective owners.

Not all the software listed above may be delivered with your model.

See the online specifications to find out what software is available for your model.

Downloaded from LpManual.com Manuals

Notice

© 2009 Sony Corporation. All rights reserved.

This manual and the software described herein, in whole or in part, may not be reproduced, translated, or reduced to any machine-readable form without prior written approval.

Sony Corporation provides no warranty with regard to this manual, the software, or other information contained herein and hereby expressly disclaims any implied warranties or merchantability or fitness for any particular purpose with regard to this manual, the software, or such other information. In no event shall Sony Corporation be liable for any incidental, consequential, or special damages, whether based on tort, contract, or otherwise, arising out of or in connection with this manual, the software, or other information contained herein or the use thereof.

In the manual, the ™ or ® marks are not specified.

Sony Corporation reserves the right to make any modification to this manual or the information contained herein at any time without notice. The software described herein is governed by the terms of a separate user license agreement.

Sony Corporation is not liable and will not compensate for any lost recordings made to your computer, external recording media, or recording devices or any relevant losses, including when recordings are not made due to reasons including your computer failure, or when the contents of a recording are lost or damaged as a result of your computer failure or repair undertaken to your computer. Sony Corporation will not restore, recover, or replicate the recorded contents made to your computer, external recording media, or recording devices under any circumstances.

Downloaded from LpManual.com Manuals

Downloaded from LpManual.com Manuals

© 2009 Sony Corporation